

ENGLISH
P17343E
AUGUST 2010

OPERATORS MANUAL & PARTS LIST

X-PRESS



SIMBA
Great Plains

ENG If you require a copy of this document in your native language please contact your dealer or Simba International Ltd. (P17343)

CZE Požadujete-li kopii tohoto dokumentu ve svém rodném jazyce, obraťte se prosím na svého prodejce nebo na společnost Simba International Ltd. (P17654)

HUN Ha szeretné ezt a leírást magyarul is megkapni, kérjük, értesitse a forgalmazóját vagy a Simba International Ltd.-t. (P17655)

FRA Pour obtenir un exemplaire du présent document dans la langue de votre choix, veuillez contacter votre représentant ou Simba International Ltd. (P17656)

LIT Jei prireiktų šio dokumento kopijos Jūsų gimtąja kalba, kreipkitės į savo platintoją arba į „Simba International Ltd“. (P17657)

BUL Ако ви е необходимо копие на този документ на родния ви език, моля да се обърнете към вашия дилър или към Simba International Ltd. (P17658)

RUM Dacă aveți nevoie de o copie a acestui document în limba dumneavoastră natală vă rugăm să vă contactați dealerul sau Simba International Ltd. (P17659)

RUS Чтобы получить копию данного документа на вашем родном языке, обратитесь к своему дилеру или в компанию «Simba International Ltd.» (P17660)

GER Wenn Sie ein Exemplar dieses Dokuments in Ihrer Muttersprache brauchen, dann wenden Sie sich bitte an Ihren Händler oder an die Simba International Ltd. (P17661)

DECLARATION OF CONFORMITY

Simba International Limited hereby declare that the **Simba X-Press**, as defined by the Serial Number attached to the Machine Chassis, conforms with the following Directives and Regulations, and has been certified accordingly.

EC Machinery Directive 2006/42/EC.

The Supply of Machinery (Safety) Regulations 2008.

The Provision and Use of Work Equipment Regulations 1998.

Specifically related harmonised standards are:

EN ISO 12100-1: 2003 (Safety of Machinery).

EN ISO 12100-2: 2003 (Safety of Machinery).

EN ISO 4254-1: 2005 (Agricultural machinery - Safety).

THE MANUFACTURER:

Simba International Limited
Woodbridge Road
SLEAFORD
Lincolnshire
NG34 7EW
England

Telephone (+44) (0)1529 304654.

CERTIFIED ON BEHALF OF SIMBA INTERNATIONAL LIMITED:



Guy Leversha
Managing Director



WARRANTY

TERMS AND CONDITIONS

In this warranty Simba International Ltd., is referred to as “the Company”.

1. Subject to the provisions of this warranty the Company warrants each new machine sold by it to be sold free from any defect in material or workmanship for a period of 12 months from date of installation with the end-user.

Some specific items have additional warranty over and above the standard 12 months. Details of these can be obtained upon request directly from the distributor or Simba International Ltd.

2. If the machine or part thereof supplied by the Company is not in accordance with the warranty given in clause 1 the Company will at its option:
 - (a) make good the machine or part thereof at the Company’s expense, or
 - (b) make an allowance to the purchaser against the purchase price of the machine or part thereof, or
 - (c) accept the return of the machine and at the buyers option either:
 - I) repay or allow the buyer the invoice price of the machine or part thereof, or
 - II) replace the machine or part thereof as is reasonably practical.
3. This warranty shall not oblige the Company to make any payment in respect of loss of profit or other consequential loss or contingent liability of the Purchaser alleged to arise from any defect in the machine or impose any liability on the Company other than that contained in clause 2.
4. Any claim under this warranty must be notified to the Company in writing specifying the matters complained of within 14 days from the date of repair.
5. Any claim under this warranty must be made by the original purchaser of the machine and is not assignable to any third party.
6. If the purchaser hires out the machine to any third party the warranty shall apply only to matters notified to the Company in writing within 90 days of the date of delivery and clause 1 shall be read as if the period of 90 days were substituted for the period of 12 months.
7. The warranty will cease to apply if:
 - (a) any parts not made, supplied or approved in writing by the Company are fitted to the machine or
 - (b) any repair is carried out to the machine other than by or with the express written approval of the Company or
 - (c) any alterations not expressly authorized by the Company in writing are made to the machine or
 - (d) the machine is damaged by accident or
 - (e) the machine is abused or overloaded or used for a purpose or load beyond its design capabilities, or used in conjunction with a tractor whose power output capability exceeds the stated implement power requirement by more than 40%. For the purpose of these terms and conditions, “stated implement power requirement” refers to wheeled tractors unless specifically stated. These power requirements should be reduced by 20% when used in conjunction with tracked tractors.
 - (f) the machine is operated as part of a ‘cultivation train’ where more than one implement is being towed, without the express written approval of Simba International Ltd.
 - (g) any maintenance is not carried out in accordance with the service schedules in the operator’s manual.
 - (h) the Installation and Warranty Registration Certificate is not received by Simba International Ltd., Service Dept., Woodbridge Road, Sleaford, Lincolnshire, England, NG34 7EW, within 7 days of installing a new machine.

Machine Identification

Enter the relevant data in the following list upon acceptance of the machine:

Serial Number	
Type of Machine	
Machine Width	
Year of Construction	
Delivery Date	
First Operation	
Accessories	

Operating Instructions/Spare Parts List: August 2010

Dealer Address: Name: _____
 Street: _____
 Place: _____
 Tel.: _____

Dealer's Customer No.: _____

SIMBA Address: SIMBA
 Woodbridge Road Ind. Est.
 Sleaford
 Lincolnshire
 NG34 7EW

Tel.: +44 (0) 1529 304654
 Fax: +44 (0) 1529 413468
 E-Mail: simba.international@simba.co.uk

SIMBA Customer No.: _____

Contents

Machine Identification	5
Introduction	8
Foreword	8
Warranty Guidelines	8
1. Safety Data	9
1.1 Safety Symbols	9
1.2 Use for the Intended Purpose	11
1.3 Operational Safety.....	11
1.4 No Liability for Consequential Damage	11
1.5 Road Traffic Safety.....	12
1.6 Accident Prevention	12
1.6.1 Hitching Up the Machine	12
1.6.2 On the Hydraulic System.....	12
1.6.3 Changing Equipment.....	13
1.6.4 During Operation	13
1.7 Servicing & Maintenance.....	13
1.8 Operating Areas	14
1.9 Authorised Operators	14
1.10 Protective Equipment	14
2. Transportation and Installation	15
2.1 Delivery	15
2.2 Transportation	15
2.3 Installation	15
2.4 Hitching Up.....	16
2.4.1 Hitching up a Tractor to the X-Press / Preparing for Transport	16
2.5 Folding and Unfolding	17
2.5.1 Unfolding into the Work Position	17
2.5.2 Folding into the Transport Position.....	17
2.6 Air Brake Coupling Procedure.....	18
2.6.1 When Coupling	18
2.6.2 When De-coupling.....	18
2.7 Preceding & Trailing Implements	19
2.7.1 Hitching a Disc Harrow to the X-Press	19
2.7.2 Transporting an X-Press Towed Behind a Disc Harrow	20
2.7.3 Changing from Work to Road Transport (X-Press Behind a Disc Harrow).....	20
2.7.4 Hitching a Rear Roll to the X-Press	20
2.8 When Driving on the Road	21
2.9 Parking the Machine.....	21
3. Technical Data X-Press	23

4.	Adjustment/Operation	24
4.1	Description	24
4.2	Disc Units	26
4.3	Double Disc Roller.....	27
4.4	Work Settings	28
4.5	Using Shims	29
4.6	Starting Settings	29
4.6.1	Variation of Settings	30
4.7	Adjusting Disc Frame Depth.....	31
4.8	Work Instructions.....	31
4.9	Checks	31
5.	Servicing and Maintenance	32
5.1	Servicing.....	32
5.2	Cleaning	32
5.3	Disc Hub Maintenance	32
5.3.1	Tightening Disc Hubs	32
5.3.2	Bearing Seals	33
5.4	Brakes & Wheel Hubs	33
5.5	Double Disc Axles	33
5.6	To Adjust the System Pressure	34
5.7	Preparation for Storage	35
5.8	Operator Support.....	35
5.9	Maintenance Intervals	35
5.10	Maintenance Overview.....	36
5.11	Lubricating the Machine	37
5.12	Handling of Lubricants.....	37
5.13	Lubricants & Hydraulic Oil	38
6.	Faults and Remedies	39
7.	Parts & Assembly.....	41

Introduction

Foreword

Make sure you have read and follow the Operating Instructions carefully before using the machine. By doing so, you will avoid accidents, reduce repair costs and downtime and increase the reliability and service life of your machine. Pay attention to the safety instructions!

SIMBA will not accept any responsibility for any damage or malfunctions resulting from failure to comply with the Operating Instructions.

These Operating Instructions will assist you in getting to know your machine and in using it correctly for its intended purposes. First, you are given general instructions in handling the machine. This is followed by sections on servicing, maintenance and the action to be taken should a malfunction occur.

These operating instructions are to be read and followed by all persons working on or with the machine, e.g.:

- Operation (including preparation, remedying of faults in the operating sequence and servicing).
- Maintenance (maintenance and inspection)
- Transportation.

Together with the Operating Instructions, you receive a Spare Parts List and a Machine Registration form. Field service technicians will instruct you in the operation and servicing of your machine. Following this, the Machine Registration form is to be returned to your dealer. This confirms your formal acceptance of the machine. The warranty period begins on the date of delivery.



We reserve the right to alter illustrations as well as technical data and weights contained in these Operating Instructions for the purpose of improving the machine.

Warranty Guidelines

The period of liability for material defects (warranty) relating to our products is 12 months. In the case of written deviations from the statutory provisions, these agreements shall apply.

They shall become effective upon installation of the machine with the end customer. All wear parts are excluded from the warranty.

All warranty claims must be submitted to SIMBA via your dealer.

1. Safety Data


The following warnings and safety instructions apply to all sections of these Operating Instructions.

1.1 Safety Symbols


On the machine




Parts may fly off during operation. Keep a safe distance away from the machine!




Read and observe the Operating Instructions before starting up the machine!



Keep clear of the working range of foldable machine components!



Watch out for escaping pressurised fluids! Follow the instructions in the Operating Instructions!




No passengers are allowed on the machine!



Never reach into areas where there is a danger of being crushed by moving parts!



Never reach into any revolving parts!





Refer to Operating Instructions before attempting maintenance.

Operating Instructions:

The Operating Instructions distinguish between three different types of warning and safety instructions. The following graphic symbols are used:



Important!



Risk of injury!



Risk of fatal and serious injuries!

It is important that all the safety instructions contained in these Operating Instructions and all the warning signs on the machine are read carefully.

Ensure that the warning signs are legible. Replace any signs that are missing or damaged.

These instructions must be followed in order to prevent accidents. Inform other users of the warnings and safety instructions.

Do not carry out any operations which may affect safe use of the machine.

All references to left and right in this manual are made from the rear of the machine, facing the direction of travel (unless otherwise stated).

1.2 Use for the Intended Purpose

The SIMBA X-Press is built using the latest technology and in accordance with the relevant recognised safety regulations. However, risks of injury for the operator or third parties and impairment of the machine or other tangible assets can arise during use.

The machine is only to be operated when in a technically perfect condition and for the intended purpose, taking into consideration safety and risks and following the Operating Instructions. In particular, faults that can impair safety are to be remedied immediately.

Original parts and accessories from SIMBA have been specially designed for this machine. Spare parts and accessories not supplied by us have not been tested or authorised. Installation or use of non-original SIMBA products may have a detrimental effect on specific design features of the machine and affect the safety of machine operators and the machine itself. SIMBA will accept no liability for damage resulting from the use of non-original parts or accessories.


The SIMBA X-Press is designed solely as a cultivation implement. Use for any other purpose, e.g., as a means of transport, will be deemed to be improper use. SIMBA will accept no liability for damage resulting from improper use. The risk will be borne solely by the operator.


Use of the X-Press behind high power tractors (in excess of 40% above the maximum recommended) can lead to high loads and stresses which can cause long term structural damage to the chassis and key components. Such overloading can compromise safety and is to be avoided.


1.3 Operational Safety

The machine is to be put in operation only after instruction has been provided by an employee of the authorised dealer or an employee of SIMBA. The "Machine Registration" form is to be completed and returned to your dealer.

All protective and safety equipment, such as removable protective equipment, must be in place and functioning reliably before the machine is put in use.

 Check screws and bolts regularly for tightness and retighten if necessary.


 In the event of malfunctions, stop and secure the machine immediately.

 Ensure that any faults are remedied immediately.

1.4 No Liability for Consequential Damage

The X-Press has been manufactured by SIMBA with great care. However, problems may still occur when it is used for the intended purpose. These may include:

- Worn wearing parts.
- Damage caused by external factors.
- Incorrect driving speeds.
- Incorrect setting of the unit (incorrect attachment, non-adherence to the Setting instructions).

 Therefore, it is crucial to always check your machine before and during operation for correct operation and adequate application accuracy.

Compensation claims for damage which has not occurred to the machine is excluded. This includes any consequential damage resulting from incorrect operation.

1.5 Road Traffic Safety

When driving on public roads, tracks and areas, it is important to observe the relevant road traffic laws as well as the specific regulations relating to this machine.



Pay attention to the permitted axle loads, tyre carrying capacity, and total weight in order to maintain adequate braking and steerability (these figures are shown on the serial plate).



Passengers on the machine are strictly forbidden!



Max. road transport speed 16mph (25km/h).

1.6 Accident Prevention

In addition to the Operating Instructions, it is important to observe the accident prevention regulations specified by agricultural trade associations. It is the Operator's responsibility to ensure that all other persons are excluded from the danger zones surrounding or on the machine during its operation.

It is the Owner's responsibility to ensure:

- the Operator is trained and competent to use the machine & tractor,
- the tractor is suitable for the machine
- adequate Risk and COSHH assessments have been undertaken regarding the machine's use. Specifically, these include issues concerning contact with the soil, dust, crop residues, chemicals, lubricants and other compounds during operation or maintenance, and the possibility of stones being ejected at high speed during work.



Beware of trapping hazards when manipulating the parking stands or other moving parts. Ensure any heavy components are fully supported when removing pins / bolts.

1.6.1 Hitching-up the machine

There is a risk of injury when hitching/unhitching the machine. Observe the following:

- Secure the machine against rolling.
- Take special care when reversing the tractor!
- There is a risk of being crushed between the machine and the tractor!
- Park the machine on firm, level ground.

1.6.2 On the Hydraulic System

Do not connect the hydraulic lines to the tractor until both hydraulic systems (machine and tractor) are depressurised.



Any hydraulic system containing an accumulator can remain under pressure permanently (even after following manual depressurisation procedures with a tractor / implement combination). It is therefore important to check all lines, pipes, and screw connections regularly for leaks and any recognisable external damage.



The hydraulic circuit contains specialised fittings which should not be tampered with under any circumstances. Do not attempt to modify hose routings or hose clamping arrangements, doing so may cause serious damage to the machine and/or injury.

Only use appropriate aids when checking for leaks. Repair any damage immediately. Spurting oil can cause injuries and fires!

In case of injury, contact a doctor immediately.

The socket and plugs for the hydraulic connections between the tractor and the machine should be colour-coded in order to avoid incorrect use.




Fig. 1.01: HydraulicTaps

1.6.3 Changing Equipment

- Secure the machine to prevent it from accidentally rolling away!
- Use suitable supports to secure any raised frame sections suspended above you!
- Caution! Risk of injury due to projecting parts!



Never climb on to rotating parts such as the roll unit. These parts may rotate causing you to slip and suffer serious injury!



Removing components during maintenance may affect the stability of the machine. Ensure it is fully supported in case of unexpected weight shifts.

1.6.4 During Operation

Ensure that the working range and the area around the machine are clear (children!) before operating the machine.

Always ensure adequate visibility!

Do not stand on the machine while it is in operation!

Operators must have a valid driving licence in order to drive on public roads. In the operating area, the operator is responsible for third parties.

The person in charge must:

- provide the operator with a copy of the Operating Instructions, and
- ensure that the operator has read and understood the instructions.
- make sure that the operator is aware of the specific regulations relating to the machine when driving on public roads.

1.7 Servicing & Maintenance

Ensure that regular checks and inspections are always carried out within the periods required by law or specified in these Operating Instructions.

When carrying out service and maintenance work always:

- switch off the tractor engine and remove the ignition key.
- wait until all the machine parts have stopped moving.
- depressurise the hydraulic system.

Many hydraulic circuits contain lock or overcentre valves which can retain pressure in the lines even after depressurising the tractor side of these circuits. If in doubt, consult trained personnel (such as your local Simba Dealer) to ensure such valves are depressurised to the correct procedure before removing or servicing any parts connected downstream of these valves.

Check all hydraulic lines for leaks, loose connections, chafe marks and damage. Remedy any deficiencies immediately! Pay particular attention to hose renewal intervals as outlined in the specific sections which follow. ALL hydraulic hoses have a safe maximum working life of 6 (SIX) years from date of installation, provided they remain in a safe condition. Hoses which exceed 6 years of age should be replaced, or inspected and certified by a suitably qualified person to have an extended life period which should be recorded.

Pay particular attention to those items which require specialist service tools or training to be carried out by qualified personnel. Do not attempt to service these items yourself! These include items retaining pressure (e.g. accumulator circuits), or force (e.g. spring tines), and DD Rolls of any type.

Prior to performing maintenance and servicing work, ensure that the machine is positioned on solid, level ground and is secured to prevent it rolling away. Do not use any parts to climb on to the machine unless they are specifically designed for this purpose.

Before cleaning the machine with water, steam jets (high-pressure cleaning apparatus) or other cleaning agents, cover all openings into which, for reasons of safety or operation, no water, steam or cleaning agents are to penetrate (bearings, for instance).

Lubricate all the lubricating points to force out any trapped water.

When carrying out servicing and maintenance work, retighten any loose screw connections.

When servicing the machine take precautions against soil, dust, seed coatings, oil or any other hazardous substances that you might encounter.

On a new machine tighten all nuts and bolts after 5 hours work and again after 15 hours. This also applies to parts that have been moved or replaced. After the initial 15 hours of work a once a week check should be sufficient depending on daily work rates.

1.8 Operating Areas

The operating areas include the drawbar, hydraulic connections and depth adjustment equipment as well as all operating points requiring maintenance.

All operating areas will be specified and described in detail in the following chapters on servicing and maintenance.

Observe all safety regulations included in the section dealing with Safety, and in the subsequent sections.

1.9 Authorised Operators

Only those persons who have been authorised and instructed by the operator may operate the machine. The operator must be at least 16 years of age.

1.10 Protective Equipment

For operation and maintenance, you require:

- Tight fitting clothing.
- Strong protective gloves (to provide protection against sharp-edged machine components).
- Protective goggles (to stop dirt getting into your eyes).

2. Transportation and Installation

Transportation and initial installation of the machine are described in this chapter.

2.1 Delivery

The machine is normally delivered, fully assembled.

- The machine can be lifted off with a crane or other suitable lifting equipment.
- The machine should be hitched to a tractor and driven off a low-loader.

2.2 Transportation

The X-Press can be transported on public roads by hitching it up to a tractor or on a low-loader.

- It is important to observe the permitted dimensions and weights when transporting the machine.
- If the machine is transported on a trailer or a low-loader, it must be secured using straps or other devices.
- Before transporting the machine on public roads, it must be adjusted to its transportation position and the stipulations relating to road transportation fulfilled.



The transportation width can vary according to the adjustment of working parts (eg. discs, roll, etc). It may be necessary to adjust these elements in order to achieve the minimum transport width.



Adjustments, including the attachment of transport devices, should be made at ground level; lowering the machine may be necessary to achieve this.

- The maximum permissible speed is 25 km /h.

2.3 Installation

When carrying out installation and maintenance work there is a higher risk of injury. It is important that you familiarise yourself with the machine and read the Operating Instructions beforehand.

Operator instruction and initial installation of the machine are carried out by our service technicians or authorised distributors.

The machine must not be used in any way beforehand! The machine can only be released for operation after instructions have been provided by our service technicians or authorised distributors.

- If any modules or parts have been removed for transportation, these shall be mounted by our service technicians/authorised dealers before the instruction takes place.
- Check all important screw connections!
- Lubricate all nipples and joints!
- Check all hydraulic connections and lines for damage.

2.4 Hitching Up

2.4.1 Hitching up a Tractor to the X-Press / Preparing for Transport



When hitching-up the machine, ensure that no-one is between the tractor and the machine.



When the X-Press is parked for extended periods of time it should ideally be left in the unfolded, i.e. work, position for stability, safety and ease of access for maintenance. However, parking the X-Press in the folded position (using the parking stands provided) is acceptable in the normal course of operation.



Tractor Oil Flow Adjustment:

As a general rule the tractor oil flow rate should be set in the lowest setting before starting. This can then be increased to allow the desired rate of operation as applicable. This will minimise excessive oil flow and consequent power usage and heat generation.

1. Ensure the tractor hydraulics are depressurised and in the locked or closed (not float) setting.
2. Ensure the rear axle taps are locked to avoid high pressure at the quick release couplings.
3. Couple the hydraulic hoses to the tractor ensuring that the two wing hoses (yellow) are together and the two drawbar cylinder hoses (red) are together.

4. Connect the tractor to the drawbar using the hydraulics to raise or lower the height of the shackle.
5. Open the rear axle taps
6. Carefully operate the hydraulics to lower the drawbar and tilt the X-Press onto the road transport wheels. Fully extend the drawbar and axle cylinders.
7. If the machine is unfolded then operate the fold circuit and fold the machine. Fit the wing strap to tie the two wing sections together.



The machine should be lowered so that the transport strap can be fitted from the ground. Do not climb on the machine.

8. Ensure that parking stands are locked up in their work positions.




Fig. 2.01: Rear Axle Cylinder




Fig. 2.02: Manifold Block

2.5 Folding and Unfolding

2.5.1 Unfolding into the Work Position

1. Ensure that the taps on the rear axle cylinder (Fig. 2.01, taps A and B) are in the open position (ie. in line with flow).
2. Remove the transport strap from the rear wing cylinders. Do not climb on the machine to remove the transport strap.
3. Lift the machine clear of the ground ready for unfolding.
4. Operate the hydraulics to fully unfold the wings.



When wings are fully lowered they will appear to be lower at the wingtips. This is to enable the machine to 'float' over uneven ground in work and is normal.

5. Ensure that the parking stands are in the fully raised position.
6. Lower the machine to the ground until the drawbar cylinders touch the depth stops.
7. Retract the rear axle cylinders completely.
8. Close the taps on the rear axle to lock the wheels clear of the ground during work.
9. Check the wing pressure on the gauge (shown in Fig. 2.02). If this is above or below the desired value then pressurise the wings to fold which will zero the setting. Increase the pressure on the cylinder side by adjusting the valve (Fig.2.02, valve 3) clockwise.

By rotating anticlockwise the pressure will be reduced (see page 34 for more details). Pressurise to unfold until the required pressure is achieved.

10. Draw the X-Press into work then set the desired pitch of the machine by adding or removing shims from the drawbar cylinder or disc frame adjusters. The chassis should ideally be set to run slightly nose high. The drawbar hydraulics may be worked in float if desired.

2.5.2 Folding into the Transport Position

1. Open the axle taps (Fig. 2.01, taps A and B).
2. Operate the hydraulics to fully raise the machine.
3. Fold the machine fully.
4. Lower the machine to maximise stability while ensuring adequate clearance for road transport.
5. Close the taps on the rear axle. Fit the transport strap for transport safety. The strap should be fitted from the ground. Do not climb on the machine.
6. The machine is ready for transport. If the X-Press is to be unhitched from the tractor in the folded position the parking stands should be lowered.



Fig. 2.03 Folded Machine

2.5.3 Following Harrow Operation

Into Work:

1. Arrive in field and unfold machine according to operating instructions
2. Whilst at rear of machine closing axle taps move Pins (qty 2) from front most holes (by lug) to rear hole.
3. Remove pin on outer quadrant plate and re-position in the highest possible hole for storage.
4. Driving forward will flip the harrow out into a work position
5. When turning in work, tip the machine rearwards into the roll. Reversing the machine in this position allows the harrow to flip temporarily into the transport position. Driving forwards again flips the harrow back into work.



Turning in work must only be on the rear roll. Attempting to lower the transport axle with the harrow in the work position will seriously damage the following harrow components.

Into Transport:

1. Tilt the X-Press onto the rear roll and reverse the machine slightly as if performing a headland turn.
2. Whilst at the rear of the machine opening the transport axle taps, move the harrow clamp pins (qty 2) from the front holes to the rear holes by the lugs.

3. Use the pin in the outer quadrant plate to the lowest position permitted that it will lock the harrow arm down.
4. Continue folding the X-Press in accordance with the operating instructions.

2.6 Air Brake Coupling Procedure

Please refer to the following procedure when coupling or decoupling any item of SIMBA machinery fitted with an AIR brake or AIR and HYDRAULIC brake system. Please note that this procedure does not apply to any machines fitted with a HYDRAULIC system ONLY.

2.6.1 When Coupling

1. Reverse up to the machine and connect the machine to the tractor as instructed to in Section 2.4.1.
2. With the machine connected couple the air lines. When coupling ensure the yellow line is attached first followed by the red line.
3. Your brake hoses are now attached and are ready for operation.
4. Continue with the coupling process as instructed in Section 2.4.1.

2.6.2 When De-coupling

1. Bring the machine to the parking position as instructed to in Section 2.9.
2. With the machine still connected to the tractor remove the red brake line followed by the yellow line.

3. Your brakes will now be ON and will hold, ensuring they have been adjusted and maintained correctly, the machine in position. (note: if the machine's tank is drained of air once all lines have been detached the brakes will come off (same situation as pushing the shunt valve).
4. Continue de-coupling the machine until it is fully disconnected.
5. Raise the X-Press drawbar above the disc drawbar (200mm approx.).
6. Raise the disc harrow to the same height as the X-Press drawbar then reverse the disc harrow to couple the two machines together. A pair of additional taps (P00774) may be required in the lift circuit of the disc harrow or the X-Press. This will isolate the drawbar circuit.



By following the above instructions you will see that at NO point in the coupling or decoupling process has the red line been left in the tractor on its own. This is intentional and should be considered the 'rule' to coupling the hoses.

2.7 Preceding & Trailing Implements

2.7.1 Hitching a Disc Harrow to the X-Press

1. Remove the transport straps from the disc harrow, exercise great CARE when extending the axle cylinder.
2. Reverse the disc harrow up to the X-Press drawbar ensuring that the two drawbars are aligned allowing a slight clearance to enable the machines to be coupled together.
3. Lower the disc harrow to the ground.
4. Connect the four hydraulic hoses from the X-Press into the disc harrow rear outlets ensuring that the two wing hoses are together and the two drawbar cylinder hoses are together. Ensure that the folding circuits and lift drawbar circuits are coupled correctly.
7. Operate the hydraulics to lower the rear axle and drawbar, tilting the X-Press onto the road transport wheels. Fully extend the drawbar cylinders.
8. Operate the hydraulics to fold the wings.
9. Operate the hydraulics to lift the disc harrow into the transport position.
10. Fit the disc harrow transport straps.
11. Fit the X-Press wing transport strap to tie the two wing sections together.
12. Ensure that parking stands are locked up in their work position.

When the X-Press is used in tandem with a disc harrow the disc should be set to the operators manual i.e. front disc gang to be 50mm closer to the ground than the corresponding disc blade on the rear gang.

With both machines in the transport position i.e. raised and folded, the top frame of the disc harrow should be slightly nose down or horizontal even when the downward load from the X-Press is applied to the drawbar of the disc harrow.

The frame may be levelled by altering the rearward tilt of the X-Press to increase or reduce the loading on the disc rear drawbar.

2.7.2 Transporting an X-Press Towed Behind a Disc Harrow

With both machines in the transport position i.e. raised and folded, the top frame of the disc harrow should be slightly nose down or horizontal even when the downward load from the X-Press is applied to the drawbar of the disc harrow. The top frame should NEVER be tail low in transport as this will give a high negative loading on the tractor which could lead to loss of traction to the rear wheels.

Extreme caution must be taken when the X-Press is transported up steep gradients and across side slopes. On the wide models, higher drawbar loading can be achieved by shortening the drawbar cylinder. Prior to leaving the field to travel on a public highway ensure that any clods of soil are removed from the machine to prevent them from fouling the road.

MAXIMUM ROAD TRANSPORT SPEED 16 MPH (25 KPH).

2.7.3 Changing from Work to Road Transport (X-Press Towed Behind a Disc Harrow)

1. Remove the disc harrow wing locking bolts.
2. Operate the hydraulics to raise the disc and X-Press.
3. Operate the hydraulics to fold the wings on both the disc harrow and the X-Press.
4. Fit the transport straps to both machines.

It may be necessary to shorten the levelling springs until the top frame of the disc harrow is horizontal or slightly nose down before moving the machines.



Shortening the X-Press drawbar cylinder will increase the loading on the rear of the disc frame. If necessary this can be used to level the disc top frame for road transport.

2.7.4 Hitching a Rear Roll to the X-Press

Follow procedure 2.4 (page 16) to couple a tractor to the X-Press. Once the tractor is safely connected to the implement and in its folded setting, raise the machine fully clear of the ground.

1. Reverse the X-Press up to the roller.
2. Align the X-Press and roller drawbars, lower the X-Press to the ground and depressurise the lift hydraulics.
3. Raise / lower the axle as required to align the respective machines' drawbars and couple together.
4. Couple the rear roll to the lift circuit of the X-Press, ensuring that the hoses are connected to the corresponding circuit on the trailing machine.
5. Couple the rear roll wing (fold) circuit to the wing (fold) circuit of the X-Press.
6. Fully raise the X-Press and the roll clear of the ground.
7. Check that all transport straps / devices are fitted.

2.8 When driving on the road

When driving on the road the machine must be converted to the transportation position.



When driving on the road, raise the machine completely to prevent the working elements dragging on the ground.

2.9 Parking the machine

In order to avoid damage as a result of moisture, the machine should be parked, if possible, indoors or under cover.



When manoeuvring the machine, pay attention to your surroundings. Ensure that nobody is in the manoeuvring area (watch for children!).

- Park the machine on level and solid ground.
- With the machine raised move the parking stands into position.
- Lower the machine onto the parking stands ensuring that it is stable.
- Remove the drawbar pin and drive forward slowly until hitch is clear of tractor drawbar.
- Lower the drawbar to the ground.
- Switch off the tractor.
- Disconnect hydraulic lines from the tractor.



3. Technical Data X-Press

	4.6m	5.5m	6.6m
Working Width	4600mm	5500mm	6600mm
Transport Width	2950mm	2950mm	2950mm
Transport Height	2790mm	2790mm	2790mm
Length	6700mm	6700mm	6700mm
Weight	5540Kg	6350Kg	7570Kg
Tractor Power Required *	140-150Hp	160-180Hp	200-220Hp
Drawbar Load **	1350Kg	1680Kg	2050Kg
Axle Load	4010Kg	4670Kg	5520Kg
Centre of Gravity ***	4536mm	4536mm	4536mm

* It is important to correctly match your implement to your tractor for optimum performance.

** Varies with lift, tilt and options.

*** Dimension from hitch in road transport.

4. Adjustment/Operation

4.1 Description




Fig. 4.01: Simba X-Press

1. Drawbar
2. Parking Stands
3. Discs
4. DD700 Roll
5. Disc Angle Adjusters
6. Disc Frame Pitch Adjusters
7. Rear Drawbar
8. Transport Wheels

The SIMBA X-Press is a versatile implement designed to perform an excellent shallow cultivation combined with effective consolidation.

It can be used in reduced tillage systems to incorporate stubble or to work down ploughing on lighter soil types. Like all Simba machines it features the latest innovations which combine to give an efficient, well-built unit with unrivalled reliability.

Consolidation is key to most operations. The design of the X-Press ensures that this is not compromised during use. This is because the penetration of the front discs is achieved by angling the disc gangs and not by transferring weight from the rear roller onto the discs. The in line rear roller ensures uniform consolidation is achieved across the field.

The X-Press can operate in situations where high levels of surface trash exist. This is possible because of the massive clearance within the machine. The front and rear disc gangs are 1050mm (42") apart and the distance between the rear gang and the roller is another 815mm (33"). The fact that the DD roller is 700mm (28") in diameter also helps ease the flow of trash and ensures that the rolling resistance is kept to a minimum.

The X-Press is designed for high speed operation at 8-12kph. The in-built weight of around 1 tonne per metre ensures that the desired depth is maintained at the optimal forward speed.

Movement from field to field or along the road is safe and simple. The X-Press wings fold vertically whilst the main frame raises parallel to the ground giving minimal height and width for transport. An optional rear drawbar allows a following implement (such as a Cambridge Roll) to be used and towed in tandem with the X-Press.

4.2 Disc Units

The X-Press features two rows of discs which chop and mix the crop residue. A disc spacing of 250mm ensures a fine tilth and being arranged in a symmetrical format around the centre line of the machine, crabbing is eliminated, leaving the machine to pull straight making the most efficient use of the power available.

The discs fitted to the X-Press are 500mm in diameter (20") and 6mm thick. They are manufactured from heat treated chrome boron steel which ensures excellent wear resistance and enhanced working life.

Each disc is mounted on a Pro-Active sprung leaf linked to a track rod system. Gang angles can be varied with ease and accuracy using a graduated adjuster.

Adjustable angling of the discs (between 10°-25°) ensures penetration and stubble mixing are achieved in one pass. Working depth can be varied simply via shimmed adjusters. All this is achieved without compromise to consolidation.

A level, evenly cultivated finish is maintained by adjusting the balance of soil throw between the front and rear disc.

Sprung Pro-Active leaves offer protection against damage as well as offering a degree of contour following as they flex up and down in work.

The centre disc unit can be adjusted independently of all other disc units to ensure a level finish across the machine width.




Fig. 4.02: Disc Frame

4.3 Double Disc Roller

The standard DD700 roller is made up of individual Double Disc (patented) Ring segments.

The DD rings are designed to consolidate the soil whilst cutting and crushing any clods.

Even in heavy, wet soils it can easily be operated with minimal blockages occurring.

The rear DD roller carries a proportion of the machine's weight to ensure consolidation. It also regulates the depth of the disc units. The corrugated surface left by the roller is weatherproof both for wet or dry situations.




Fig. 4.03: Double Disc Roller

4.4 Work Settings

In work the wing cylinders should be fully extended. The gangs are able to float over any undulations on the ground due to their floating frames. A simple pressurised hydraulic circuit automatically sets itself as the wings are unfolded.

Optimum performance has been found to be achieved when the press roll rings have worn away the painted finish leaving a smooth shiny surface. When the press roll rings are new or rusty, soil may tend to pick up on the surface and blockage may occur, this will reduce when the rings are shiny again.

The X-Press should be run with the chassis slightly nose high by extending the drawbar cylinders to the necessary position. In practice it is possible to use the X-Press on ground conditions that are unsuitable to achieve the desired effect, and it is usually possible to operate the press without regular blockage under such unsuitable conditions, assuming that the axles are tight and rings smooth. As such, especially under wet conditions, it is advisable to check on the cultivation effect of the machine.

It is not necessary to tilt the X-Press onto the transport wheels during headland turns whether the machine is used independently or in tandem with a disc harrow. The X-Press should be tilted onto the roll until the discs clear the ground (at which point the rear axle wheels will still be clear of ground contact).

General Rules when Setting the X-Press

- The lighter the land conditions the less the disc angle required and the forward speed can be increased.
- The wetter the land conditions the less the disc angle required and the forward speed will need to be decreased.
- Heavier land will require more of a disc angle and a slower forward speed.
- The more the trash the less the angle on the discs and forward speed will have to be decreased.
- On ploughed land reduce the disc angle to give a cutting/chopping action.
- In hard conditions increase the disc angle to increase penetration.

Disc Angle Setting



4.5 Using Shims

Before using shims to alter machine settings ensure the machine is stationary and the tractor is turned off with the keys out. Ensure that all operators are clear of the machine and that no load is being held on any existing shims in the cylinder / depth control rod.

To fit the shims hold them by the handle and, using a firm action, clip them onto the rod as shown in *Fig. 4.04*. They are removed by using a finger to pull firmly on the handle.



Check the cylinder / depth control rod for damage and debris before fitting shims.



Only attempt to add or remove shims using the handle. Trying to manipulate shims using the jaws could result in injury.



When changing machine settings ensure both sides of the machine mirror each other. The left hand cylinder should contain the same amount of shims as the right, for example. Failure to do this could result in damage to the machine.





Fig. 4.04: Shims

4.6 Starting Settings

The following pages detail the recommended starting settings for the X-Press. These settings can then be used as a base for further adjustment in order to get the optimum performance from your machine.


Ensure all settings from the left and right hand sides of the machine mirror each other.

Drawbar Cylinder




The drawbar cylinder shim settings are subject to the tractor drawbar height. As such, the shim settings shown above are intended as a suggestion only. The machine should be set to run with the chassis level to nose high depending upon working depth.

Disc Frame Pitch



The centres of the adjuster should be factory set to 640mm when the machine is received. This is an ideal starting point before beginning to add shims to set the disc pitch.

Disc Angle Adjustment Jacks



4.6.1 Variation of Settings

If working conditions change (for example, from dry to wet conditions) then the following table should be consulted as a rough guide.

VARIATION IN CONDITION	SETTING REVISION
FROM HARD/DRY TO LOOSE/WET	REDUCE DISC ANGLE
	INCREASE DISC FRAME PITCH & DRAWBAR SHIM LENGTH (RATIO 2 DRAWBAR : 1 DISC PITCH)
FROM STUBBLES TO HIGHER TRASH (TO INCREASE INCORPORATION)	INCREASE DISC ANGLE
	REDUCE SPEED
	INCREASE DRAWBAR SHIMS
FROM SHALLOW TO DEEP (NOTE 75- 100mm MAX WORKING DEPTH)	DECREASE DISC FRAME PITCH & DRAWBAR SHIM LENGTH (RATIO 2 DRAWBAR : 1 DISC PITCH)
	INCREASE DISC ANGLE
	REDUCE SPEED

4.7 Adjusting Disc Frame Depth

Adjustment of the disc frame depth is achieved by lengthening or shortening the adjusters as required in combination with raising or lowering the disc frames relative to the DD roller by adding or removing drawbar shims (for example, to increase disc depth remove drawbar shims and adjust the turnbuckle as required). Once set, the adjusters should be locked by adding shims to the lower end thread and tightening.

To change the settings it is advisable to lift the disc frames just clear of the ground so that the adjusters can be lengthened enough to fit the amount of shims required. When the shims have been fitted the machine can be lowered, making it easier to tighten the adjuster against the shims.

4.8 Work Instructions

Driving speed

The X-Press can be driven at speeds of up to 12 km/h.

This depends on the field conditions (type of soil, surface trash, etc.).

Drive more slowly if the conditions are difficult or a firmer finish is required.

Turning:



Before turning, the machine should be eased out of work onto the rear roll while driving and should be eased back into work once the turn has been completed.

Parking the Machine

In order to avoid damage as a result of moisture, the machine should be parked, if possible, indoors or under cover.



When manoeuvring the machine, pay attention to your surroundings. Ensure that nobody (children!) is in the manoeuvring area.

- Park the machine on level and solid ground.
- With the machine raised move the parking stands into position.
- Lower the machine onto the parking stands ensuring that it is stable.
- Remove the drawbar pin and drive forward slowly until hitch is clear of tractor drawbar.
- Lower the drawbar to the ground.
- Switch off the tractor.
- Disconnect hydraulic lines from the tractor.

4.9 Checks

The working quality depends on the adjustments and checks made prior to and during work, as well as on regular servicing and maintenance of the machine.

Before beginning work it is therefore important to carry out any necessary servicing and to lubricate the machine as required.

Checks prior to, and during work:

- Is the machine correctly hitched up and the coupling device locked?
- Have the hydraulic lines been connected according to the colour coding?
- Is the machine in a level operating position and the working depth set correctly?

Working Elements

- Are the discs and other cultivation tools in a serviceable condition?
- Are the scrapers still operable, so that the rolls do not jam?

5. Servicing and Maintenance



Follow the safety instructions for servicing and maintenance.

5.1 Servicing

Your machine has been designed and constructed for maximum performance, operational efficiency and operator friendliness under a wide variety of operating conditions.

Prior to delivery, your machine has been checked at the factory and by your authorised dealer to ensure that you receive a machine in optimum condition.



To ensure trouble-free operation, it is important that servicing and maintenance work is performed at the recommended intervals.

5.2 Cleaning

In order to ensure that the machine is always in operating condition and to achieve optimum performance, perform the cleaning and servicing work at regular intervals.

Avoid cleaning the roll / disc bearings with a high- pressure hose or a direct water jet. The housing, screwed connections and ball bearings are not watertight.

5.3 Disc Hub Maintenance



Grease every disc hub until grease shows from the seals according to the lubricating intervals outlined on page 36.



Check disc hubs regularly for tightness.



Regularly examine hub caps, seals and pivot bolts and all tracking bolts for tightness and effectiveness twice weekly or every 50 working hours (whichever is more frequent).

5.3.1 Tightening Disc Hubs

- 1 Ensure that the bearing seal is in the correct orientation when replacing / assembling components.
- 2 Ensure that the stub axle is free from dirt and the nut and outer bearing can easily slide on it.
- 3 Tighten the crown nut with a hand spanner (a torque wrench is not required) while turning the hub clockwise until the bearing drags slightly (you feel the hub turning heavily). Some resistance will be due to friction from the seal.
- 4 Turn back the crown nut to the next locking position. Even if the tightening of the nut has reached an exact fixing position, turn it back.
- 5 Insert the retaining pin.
- 6 Try to shake/rock the outer edge of the hub/spindle: play of 0.1 / 0.2mm will not reduce the bearings' life and, in addition, prevents overheating. If the adjustment is correct the hub should turn freely with the only friction being from the seal.



Fig. 5.01: Checking Disc Bearing Adjustment

5.3.2 Bearing Seals

It is important when replacing the labyrinth type bearing seals in disc hubs that the seal is fitted the right way round. The chamfered lip side should be at the outside of the bearing housing, nearest the disc arm (see *Fig. 5.02*). This chamfered lip prevents dirt ingress into the housing and also allows grease to be flushed through when greasing.




Fig. 5.02: Correct Seal Orientation

5.4 Brakes & Wheel Hubs

The brakes should be tested before using for the first time and after the first laden journey.



Check that the road and parking brakes operate and release correctly before using the machine.



Check for hydraulic fluid and air leaks.



Brake and hub maintenance and servicing should be carried out by an authorised Simba dealer.

5.5 Double Disc Axles

The axles on this roller are tensioned by the main axle through the centre of the rings and bearings.



Specialist equipment is required for the disassembly of Double Disc axles. Please consult your dealer under any circumstances that require disassembly of these axles.

Maintenance of these rollers is limited to daily greasing of the bearings to flush out dirt, and regular inspection to ensure the assemblies are tight, and scrapers are correctly set. The axles can be tightened provided the bearing pillar 'U' bolts are loosened to avoid preloading the bearings as they move sideways to each other. Ensure the bearing pillars are re-tightened to the mainframe after this.

5.6 To Adjust the System Pressure



A low oil flow should be used, i.e., tractor tickover or low flow selected.



The wing circuit is controlled by an overcentre valve contained within the manifold block which positively locks oil flow until pressurised by the tractor. System pressure can be retained in the circuit **even after depressurisation** of the tractor quick release couplings.



Exercise extreme care when checking the valve or circuits, and *under no circumstances* attempt to adjust or loosen fittings without prior reference to your authorised simba dealer, and detailed maintenance instructions.

It is normal to operate at 10-20 bar. This can be increased to 40-50 bar max, or reduced to 5 bar as conditions determine. Higher pressure will cause the wing tips to dig in causing the centre of the machine to lift it out. Too little pressure will cause the wing tips to lift out & the centre of the machine to dig in. When towing another implement behind the X-Press, the pressure may need increasing to compensate.

In all cases the normal adjustment method is to minimise system pressure and then increase by adjusting the pressure valve until the desired pressure is achieved.

In all cases, regardless of tractor make, adjustment should start from zero (minimum pressure) and gradually increase up to desired pressure value.

With the machine off the ground,

1. Pressurise the wings to unfold. As the unfolding begins the pressure reading on the gauge will drop. When the wings have fully unfolded the pressure reading will start to climb. Keep pressurising the wings until the gauge has stabilised at the pre-set pressure. The standard factory setting is 15 bar.
2. If the system needs adjusting:- Partially fold the wings & hold them in this position. To adjust the pressure utilise valve 3 (shown in Fig. 5.03). Unscrew the adjusting screw until no resistance can be felt (almost fully unscrewed position). Unfold the wings fully as before, checking the gauge reading. Maintain hydraulic pressure unfolding wings & adjust the screw whilst pressurising.
 - Turning adjuster clockwise increases pressure.
 - Turning adjuster anti-clockwise decreases pressure.

Once the desired pressure is achieved lock the valve. As a check, partially fold the wings, stop, and then unfold again maintaining pressure until the gauge stabilises at your desired setting.




Fig. 5.03: Manifold Block

5.7 Preparation for Storage

If you need to store the machine for a longer period, observe the following points:

- Park the machine undercover if possible.
- Protect the roll / discs against rust. If you need to spray the implements with oil, use light biologically degradable oils, e.g. rape oil.



Cover any rubber sections before using oil sprays. These sections must not be oiled.

Remove any traces of oil with a suitable cleaning agent.

5.8 Operator Support

If you have a problem, please contact your dealer. They will endeavour to solve any problems which may occur and provide you with support at all times.

In order to enable your dealer to deal with problems as quickly as possible, it helps if you can provide them with the following data. Always state the:

- Customer Number
- Name and Address
- Machine Model
- Serial Number of Machine
- Date of Purchase and Operating Hours
- Type of Problem

5.9 Maintenance Intervals

Apart from daily maintenance, the maintenance intervals are based on the number of operating hours and time data.

Keep a record of your operating hours to ensure that the specified maintenance intervals are adhered to as closely as possible.

Never use a machine that is due for maintenance. Ensure that all deficiencies found during regular checks are remedied immediately.




Avoid sharp-edged and pointed parts (disc blades, etc.) when working on the machine.



Place the machine on suitable supports when working underneath! Do not work under a machine which is not supported!

On a new machine tighten all nuts and bolts after 5 hours work and again after 15 hours. This also applies to parts that have been moved or replaced. After the initial 15 hours of work a once a week check should be sufficient depending on daily work rates.

5.10 Maintenance Overview



5.11 Lubricating the Machine

Please read the section entitled “Using Lubricants” carefully before lubricating the machine. The machine must be lubricated regularly in order for it to remain serviceable. Regular lubrication also contributes towards extending the service life of your machine. The recommended lubricating intervals are specified in “Inspection” and “Maintenance Intervals”.

After it has been washed using a high-pressure hose or steam cleaned, the machine should always be lubricated using a grease gun.

5.12 Handling of Lubricants

Please ensure that you read the following instructions as well as the relevant information. This also applies to any of your employees who handle lubricants.

Hygiene

Lubricants do not present a health hazard provided they are used for their specified purpose.

In the case of prolonged skin contact, lubricants - especially low-viscosity oils - may remove the natural layer of fat contained in the skin, resulting in dryness and possible irritation .

It is important to take extreme care when handling waste oil as it may contain other irritants.

Vapours given off by cleaning agents and oils are also a potential health hazard. You should therefore not carry any oily cloths around. Change soiled work clothing as soon as possible.

Always exercise extreme care and observe the recommended hygiene rules when handling mineral oil products. Details of these handling regulations can be found in information provided by the health authorities.

Storage and Handling

- Always store lubricants where they cannot be accessed by children.
- Never store lubricants in open or unlabelled containers.

Fresh Oil

- Apart from taking the usual care and observing hygiene rules, there is no need to take any special precautions when handling fresh oil.

Waste Oil

- Waste oil can contain harmful contaminants which may cause skin cancer, allergies and other illnesses.

Attention!

Oil is a toxic substance. Should you swallow any oil, do not try to vomit. Contact a doctor immediately.

Protect your hands with barrier cream or wear gloves to avoid contact with the skin. Wash off any traces of oil thoroughly with soap and hot water.

- Wash your skin thoroughly with soap and water.
- Use special cleaning agents to clean any dirt off your hands.
- Never wash oil residue from your skin with petrol, diesel fuel or paraffin.
- Avoid skin contact with any oily clothing.
- Do not keep any oily rags in your pockets.
- Wash soiled clothing before wearing it again.
- Ensure that any oily footwear is disposed of in the proper manner.

Measures in case of injury through oil

Eyes:

Should any oil be splashed into your eyes, rinse with water for 15 minutes. If the eye is still irritated, contact a doctor immediately

If oil is swallowed

If oil is swallowed, it is important not to induce vomiting. Contact a doctor immediately.

Skin irritation caused by oil

In case of prolonged skin contact, wash off the oil with soap and water.

Oil Spills

Use either sand or a suitable granular absorbent to soak up any spilt oil. Dispose of the oil-contaminated absorbent in the proper manner.

Oil Fires

Never use water to extinguish an oil fire. The oil will float on the water causing the fire to spread.

Burning oil-lubricant must be extinguished using a carbon dioxide powder or foam extinguisher. Always wear respiratory equipment when dealing with fires of this type.

Waste Oil Disposal

Oil-contaminated waste and used oil must be disposed of in accordance with current legislation.

Waste oil must be collected and disposed of in accordance with local regulations. Never pour used oil into unsealed sewage systems or drains or onto the ground.

5.13 Lubricants & Hydraulic Oil

Hydraulic System

The hydraulic fluid from the tractor is mixed with the hydraulic fluid from the machine.

The supplied machine hydraulic system contains Total AZOLLA ZS 32 oil.

Lubricants

Simba strongly recommend the use of **Lithium Complex EP2 Grease** in the disc and wheel hubs of your X-Press. This grease is a Lithium Complex soap dispersed in a mineral oil and is interpreted by IARC as being non-carcinogenic. Grease cartridges are available from Simba (P12710). Using this grease in combination with the labyrinth type seal it is permissible to lengthen the greasing interval on the disc hubs to 200 hours. If using a standard agricultural grease the disc hubs should be lubricated every 50 hours.

Advantages of Lithium Complex EP2 Grease

- Excellent mechanical stability.
- Excellent load carrying properties.
- Wide temperature range.
- Excellent oxidation stability.
- Excellent water resistance.
- Compatibility with other greases.

All other lubricating points on the machine can be lubricated with multigrade lubricating grease as specified in DIN 51825 KP/2K - 40.

6. Faults and Remedies


X-Press Troubleshooting		
Fault	Possible Cause	Remedy
Wings riding up at outside of machine.	Wings not pressured down.	Raise onto transport wheels and pressure wings down.
	Wing pressure too low.	Increase wing pressure.
	Hard conditions.	Increase wing pressure.
Centre section riding up.	Wing pressure too high.	Reduce wing pressure.
Machine 'bouncing' in work.	Disc angle too great.	Reduce disc angle.
	Speed too fast.	Reduce speed (<12kmh).
DD Roll blocks regularly.	Scrapers incorrectly adjusted	Adjust scrapers to clear dirt from between DD Rings.
	Conditions may not be ideal for using machine.	Wait for more favourable conditions.

Space for Notes:


7. Parts & Assembly


Table of contents

General Assembly.....	42	Brakes	116
4.6m Full Assembly	42	Braked Axle - Air	116
5.5m Full Assembly	44	Air Tank & Fittings.....	118
6.6m Full Assembly	46	Braked Axle - Hydraulic	120
Drawbar Assembly.....	48	Hydraulic Brakes Hose Layout	122
Chassis Assembly	50	Hydraulics	124
Lift Axle Assembly.....	52	Lift Circuit Components	124
Rear Drawbar Assembly.....	54	Lift Circuit.....	126
Eradicator Tine Kit	56	Wing Circuit Components (4.6m)	128
Loadbinder Assembly	58	Wing Circuit (4.6m).....	130
Disc Frames	60	Wing Circuit Components (5.5 & 6.6m).....	132
4.6m Disc Frame Assembly RH.....	60	Wing Circuit (5.5 & 6.6m)	134
4.6m Disc Frame Assembly LH	62	Rear Drawbar Hydraulics	136
5.5m Disc Frame Assembly RH.....	64		
5.5m Disc Frame Assembly LH	66		
6.6m Disc Frame Assembly RH.....	68		
6.6m Disc Frame Assembly LH	70		
Disc Unit Assembly RH.....	72		
Disc Unit Assembly LH	74		
Disc Unit Assembly Centre	76		
Disc Hub Assembly RH	78		
Disc Hub Assembly LH.....	80		
Disc Frame Adjuster	82		
Roll Carriers.....	84		
4.6m Roll Carrier Assembly RH.....	84		
4.6m Roll Carrier Assembly LH	86		
5.5m Roll Carrier Assembly RH.....	88		
5.5m Roll Carrier Assembly LH	90		
6.6m Roll Carrier Assembly RH.....	92		
6.6m Roll Carrier Assembly LH	94		
Double Disc Roll.....	96		
Double Disc Roll Assembly 4.6m RH	96		
Double Disc Roll Assembly 4.6m LH.....	98		
Double Disc Roll Assembly 5.5m RH ..	100		
Double Disc Roll Assembly 5.5m LH... ..	102		
Double Disc Roll Assembly 6.6m RH ..	104		
Double Disc Roll Assembly 6.6m LH... ..	106		
Double Disc Axle Assembly 5 rings	108		
Double Disc Axle Assembly 6 rings	110		
Double Disc Axle Assembly 7 rings	112		
Double Disc Pillar Assembly.....	114		





DESCRIPTION: X-PRESS 4.6M COMPLETE MACHINE	MACHINE: X-PRESS 2010	 © 2009	DRAWN:- AGD DATE:- 29/10/2009	PART NO. FROM SERIAL NO. TO SERIAL NO.	ASSEMBLY AS3809	ISSUE A
---	--------------------------	--	----------------------------------	--	--------------------	------------

AS3809		X-PRESS COMPLETE MACHINE 4.6m		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	AS2157	DISC FRAME ADJUSTER ASSEMBLY	2	
2	AS2158	LIFT CIRCUIT - HYD. COMPONENT LAYOL	1	
3	AS2748	WING CIRCUIT - HYD. COMPONENTS	1	
4	AS2849	LOADBINDER ASSEMBLY 530mm	1	
5	AS3252	ROLL FRAME ASSEMBLY - RH 4.6m	1	
6	AS3253	ROLL FRAME ASSEMBLY - LH 4.6m	1	
7	AS3258	DD700 ROLL ASSEMBLY RH	1	
8	AS3259	DD700 ROLL ASSEMBLY LH	1	
9	AS3273	STICKER KIT X-PRESS 4.6m	1	
10	AS3806	X-PRESS DRAWBAR ASSEMBLY	1	
11	AS3807	CHASSIS ASSEMBLY	1	
12	AS3808	LIFT AXLE ASSEMBLY	1	
13	AS3812	DISC FRAME RH 4.6m	1	
14	AS3813	DISC FRAME ASSEMBLY LH	1	
15	P14202	HYDRAULIC KIT - 5.5m+6.6m X-RPESS	1	
16	P15895	WIRING LOOM - X-PRESS	1	
17	P17343	MANUAL - X-PRESS 2010	1	
18				
19	AS2818	27/10-12 RUBBER ROLL ASSEMBLY	2	(NOT SHOWN)
20	AS3452	DDL600 - X-PRESS 4.6M BOLT ON KIT	1	(NOT SHOWN)
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				





DESCRIPTION: X-PRESS 5.5M COMPELTE MACHINE	MACHINE: X-PRESS 2010	© 2009	DRAWN:- AGD DATE:- 29/10/2009	PART NO. FROM SERIAL NO. TO SERIAL NO.	ASSEMBLY AS3810	ISSUE A
---	--------------------------	--------	----------------------------------	--	--------------------	------------

AS3810		X-PRESS COMPLETE MACHINE 5.5m		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	AS2157	DISC FRAME ADJUSTER ASSEMBLY	2	
2	AS2158	LIFT CIRCUIT - HYD. COMPONENT LAYOL	1	
3	AS2160	WING CIRCUIT - HYD. COMPONENTS	1	
4	AS2849	LOADBINDER ASSEMBLY 530mm	1	
5	AS3254	ROLL FRAME ASSEMBLY - 5.5m RH	1	
6	AS3255	ROLL FRAME ASSEMBLY 5.5m LH	1	
7	AS3260	DD700 ROLL ASSEMBLY - 5.5m RH	1	
8	AS3261	DD700 ROLL ASSEMBLY - 5.5m LH	1	
9	AS3274	STICKER KIT X-PRESS 5.5m	1	
10	AS3806	X-PRESS DRAWBAR ASSEMBLY	1	
11	AS3807	CHASSIS ASSEMBLY	1	
12	AS3808	LIFT AXLE ASSEMBLY	1	
13	AS3814	DISC FRAME ASSEMBLY 5.5m RH	1	
14	AS3815	DISC FRAME ASSEMBLY 5.5m LH	1	
15	P17343	MANUAL - X-PRESS 2010	1	
16	P14202	HYDRAULIC KIT - 5.5M X-PRESS	1	
17	P15895	WIRING LOOM - X-PRESS	1	
18				
19	AS2819	27/10-12 RUBBER ROLL ASSEMBLY	2	(NOT SHOWN)
20	AS3453	DDL600 - X-PRESS 6.6M - BOLT ON KIT	1	(NOT SHOWN)
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				





DESCRIPTION: X-PRESS 6.6M COMPELTE MACHINE	MACHINE: X-PRESS	© 2009	DRAWN:- KSL DATE:- 02/11/2009	PART NO. FROM SERIAL NO. TO SERIAL NO.	ASSEMBLY AS3811	ISSUE A
---	---------------------	--------	----------------------------------	--	--------------------	------------

AS3811		GENERAL ASSEMBLY - 6.6m		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	AS2157	DISC FRAME ADJUSTER ASSEMBLY	4	
2	AS2158	LIFT CIRCUIT - HYD. COMPONENT LAYOL	1	
3	AS2160	WING CIRCUIT - HYD. COMPONENTS	1	
4	AS2849	LOADBINDER ASSEMBLY 530mm	1	
5	AS3256	ROLL FRAME ASSMEBLY - RH 6.6m	1	
6	AS3257	ROLL FRAME ASSEMBLY L - LH 6.6m	1	
7	AS3262	DD700 ROLL ASSEMBLY - 6.6m RH	1	
8	AS3263	DD700 ROLL ASSEMBLY - 6.6m LH	1	
9	AS3275	STICKER KIT X-PRESS 6.6m	1	
10	AS3806	X-PRESS DRAWBAR ASSEMBLY	1	
11	AS3807	CHASSIS ASSEMBLY	1	
12	AS3808	LIFT AXLE ASSEMBLY	1	
13	AS3816	DISC FRAME ASSEMBLY 6.6m RH	1	
14	AS3817	6.6m DISC FRAME ASSEMBLY LH	1	
15	P14202	HYDRAULIC KIT - 5.5m+6.6m X-RPESS	1	
16	P15897	WIRING LOOM - TRAILED X-PRESS	1	
17	P17343	MANUAL - X-PRESS 2010	1	
18				
19	AS2820	27/10-12 RUBBER ROLL ASSEMBLY	2	(NOT SHOWN)
20	AS3454	DDL600 - X-PRESS 6.6M - BOLT ON KIT	1	(NOT SHOWN)
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				





DESCRIPTION:- X-PRESS DRAWBAR ASSEMBLY	MACHINE:- X-PRESS	© 2005	DRAWN:- P.J.G DATE:- 29/10/2009	PART NO. FROM SERIAL NO. TO SERIAL NO.	ASSEMBLY AS3806	ISSUE A
--	----------------------	--------	------------------------------------	--	---------------------------	-------------------

AS3806		X-PRESS FRONT DRAWBAR		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	P00002	BOLT U M12 GR8.8 70x54	2	
2	P00045	BOLT M36x200 GR. 8.8	2	
3	P02007	NUT LOCK M12	10	
4	P02012	NUT LOCK M36	2	
5	P02483	LYNCH PIN CAT 1	1	
6	P02600	WASHER FLAT M10	2	
7	P02601	WASHER FLAT M12	12	
8	P02604	WASHER FLAT M24 Ø50	4	
9	P02609	WASHER FLAT M39	2	
10	P03089	BOLT M12x65 GR. 8.8	2	
11	P04754	NUT LOCK M8	8	
12	P05492	NUT LOCK 1" UNF	2	
13	P05534	NUT LOCK M10	2	
14	P05535	WASHER FLAT M8	16	
15	P06651	BOLT M10x25 GR. 8.8	2	
16	P08548	BOLT 1" UNFx7" GR. V	2	
17	P08997	HITCH - FRONT	1	
18	P09092	HOSE STOWAGE PLATE	1	
19	P09112	CLAMP ½" BSP PAIR	3	
20	P09113	CLAMP - TOP PLATE	2	
21	P09597	BOLT M8x25 GR. 8.8	8	
22	P10278	BOLT M8x45 GR. 8.8	1	
23	P12284	X-PRESS DRAWBAR	1	
24	P12507	BOLT M8x80 GR. 8.8	1	
25	P14001	HOSE MAST - X-PRESS	1	
26	P14029	PIN Ø30x138	1	
27	P15560	LIGHT BOARD FRH	1	
28	P15561	LIGHT BOARD FLH	1	
29	P16007	SOCKET PLATE 12N	1	
30	P16360	CAT3-CAT2 BUSH INSERT	1	
31	P17341	LIGHT MOUNT	1	
32	P17342	LIGHT ARM MOUNT	2	
33	P08012	BOLT M12x45 GR8.8	4	
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				





DESCRIPTION:- CHASSIS ASSEMBLY		MACHINE:- TRAILED X-PRESS	 © 2007		DRAWN:- PJJG DATE:- 29/10/2009	PART NO.	FROM SERIAL NO. TO SERIAL NO.	ASSEMBLY AS3807	ISSUE A
--	--	------------------------------	--	--	-----------------------------------	----------	-------------------------------	---------------------------	-------------------

AS3807		X-PRESS CHASSIS		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	P00047	BOLT M36x240 GR. 8.8	4	
2	P00071	NIPPLE - GREASE	4	
3	P01645	BUSH SPRUNG - Ø32xØ26x30	4	
4	P02010	NUT LOCK M24	4	
5	P02012	NUT LOCK M36	4	
6	P02483	LYNCH PIN CAT 1	4	
7	P02604	WASHER FLAT M24 Ø50	16	
8	P02609	WASHER FLAT M39	4	
9	P02789	BOLT M8x20 GR. 8.8	2	
10	P04233	SPANNER - M60	2	
11	P04753	BOLT M8x60 GR. 8.8	2	
12	P07543	PLASTIC END CAP 40x40	2	
13	P08802	SHIM KIT 7 PIECE	1	
14	P08817	WASHER SPRING M8	4	
15	P09112	CLAMP ½" BSP PAIR	4	
16	P09113	CLAMP - TOP PLATE	2	
17	P10049	BOLT M8x25 STAUFF STACK	2	
18	P10234	LOCK CLIP	2	
19	P10278	BOLT M8x45 GR. 8.8	2	
20	P11689	BOLT M8x110 GR. 8.8	2	
21	P12610	BOLT M24x120 GR 10.9 STR	4	
22	P13013	MANUAL CASE Ø100	1	
23	P14003	PARKING STAND - X-PRESS	2	
24	P14027	PIN Ø25x118 HANDLED	2	
25	P14028	PIN Ø30x159	2	
26	P14031	BUSH Ø45xØ36.5x40	8	
27	P14963	CHASSIS	1	
28	P16016	TRAILER SOCKET BULKHEAD	1	
29	P16312	MANUAL TUBE BRACKET	1	
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				





DESCRIPTION:- LIFT AXLE ASSEMBLY	MACHINE:- X-PRESS	DRAWN:- P.J.G DATE:- 29/10/2009	SIMBA © 2006	PART NO. FROM SERIAL NO. TO SERIAL NO.	ASSEMBLY AS3808	ISSUE A
--	----------------------	------------------------------------	--------------	--	---------------------------	-------------------

AS3808		LIFT AXLE ASSEMBLY		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	AS2364	REAR DRAWBAR ASSEMBLY	1	
2	P01293	BOLT M36x280 GR. 8.8	2	
3	P01901	BOLT M16x80 GR. 8.8	18	
4	P02007	NUT LOCK M12	8	
5	P02008	NUT LOCK M16 'TYPE T'	18	
6	P02012	NUT LOCK M36	2	
7	P02483	LYNCH PIN CAT 1	1	
8	P02601	WASHER FLAT M12	16	
9	P02602	WASHER FLAT M16	22	
10	P03088	BOLT M12x60 GR. 8.8	8	
11	P03788	WHEEL ASSEMBLY - 500/50	2	
12	P04754	NUT LOCK M8	8	
13	P05535	WASHER FLAT M8	16	
14	P09597	BOLT M8x25 GR. 8.8	8	
15	P13033	HUB ASSEMBLY 6 STUD COMPLETE	2	
16	P14007	BOTTOM AXLE	1	
17	P14024	BACK PLATE	3	
18	P14025	PIN Ø30x129	1	
19	P15562	LIGHT BOARD RRH	1	
20	P15563	LIGHT BOARD RLH	1	
21	P15945	LIFT AXLE	1	
22	P16899	LIGHT ARM MOUNT LH	1	
23	P16900	LIGHT ARM MOUNT RH	1	
24	P16901	LIGHT ARM REAR LH	1	
25	P16902	LIGHT ARM REAR RH	1	
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				





DESCRIPTION:- REAR DRAWBAR ASSEMBLY	MACHINE:- X-PRESS	 © 2005	DRAWN:- P.J.G DATE:- 30/11/2005	PART NO. FROM SERIAL NO. TO SERIAL NO.	ASSEMBLY AS2364	ISSUE A
---	----------------------	--	------------------------------------	--	---------------------------	-------------------


AS2364		REAR DRAWBAR ASSEMBLY		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	P08836	HELPER LEAF	1	
2	P02608	WASHER FLAT M30	2	
3	P14026	PIN Ø32x138 HANDLED	1	
4	P02483	LYNCH PIN CAT 1	1	
5	P02011	NUT LOCK M30	1	
6	P00006	BOLT M12x80 GR. 8.8	1	
7	P02601	WASHER FLAT M12	1	
8	P02007	NUT LOCK M12	1	
9	P14006	REAR HITCH	1	
10	P00056	BOLT M30x240 GR. 8.8	1	
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				




DESCRIPTION: ERADICATOR TINE KIT	 © 2004	DRAWN:- AGD DATE:- 23/06/2004	PART NO. FROM SERIAL NO. TO SERIAL NO.	ASSEMBLY AS1637	ISSUE A
-------------------------------------	--	----------------------------------	--	--------------------	------------


AS1637		ERADICATOR KIT X-PRESS		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	P12809	ERADICATOR TINE BEAM	2	
2	P05207	PIN Ø16x73	6	
3	P12524	TINE CLAMP UNIT	6	
4	P12525	BUSH Ø25xØ16.5x26	6	
5	P12575	RETAINING PLATE	6	
6	P02602	WASHER FLAT M16	74	
7	P02008	NUT LOCK M16	66	
8	P11494	BOLT M16x55 GR. 8.8	12	
9	P07546	PLASTIC END CAP 80x80	4	
10	P12573	PRO-ACTIVE 150x12	6	
11	P12574	BOLT U M16 130/115-86 GR8.8	12	
12	P00007	BOLT M16x40 GR. 8.8	18	
13	P02485	R CLIP Ø6x120	6	
14	P12628	TINE 2x1 SHORT	6	
15	P01102	BOLT M16x70 GR. 8.8	12	
16	P03017	POINT 1½" REVERSIBLE	6	
17	P03448	BOLT 7/16" UNFx75	12	
18	P07131	NUT LOCK 7/16"UNF	12	
19				
20				
21				
22				
23		QUANTITY SHOWN PER MACHINE		
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				




AS2849		LOADBINDER ASSEMBLY - 530mm		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	P02008	NUT LOCK M16	1	
2	P02602	WASHER FLAT M16	2	
3	P09280	BOLT M16x45 GR8.8	1	
4	P14687	SHACKLE - BOW 2T M16	2	
5	P14762	RATCHET LOADBINDER	1	
6	P15289	LOABINDER LINK 530mm	1	
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				





DESCRIPTION: DISC FRAME RH 4.6m	MACHINE: X-PRESS 4.6m	© 2005	DRAWN: P.JG DATE: 29/10/2009	PART NO. FROM SERIAL NO. TO SERIAL NO.	ASSEMBLY AS3812	ISSUE A
------------------------------------	--------------------------	--------	---------------------------------	--	--------------------	------------

AS3812		DISC FRAME RH 4.6m X-PRESS		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	AS3210	DISC UNIT ASSEMBLY RH	9	
2	AS3211	DISC UNIT ASSEMBLY LH	9	
3	P00036	BOLT M30x180 GR. 8.8	2	
4	P00874	BOLT M20x70 GR. 8.8	4	
5	P01704	BOLT M16x50 GR8.8	36	
6	P01901	BOLT M16x80 GR. 8.8	36	
7	P02008	NUT LOCK M16 'TYPE T'	72	
8	P02009	NUT LOCK M20	4	
9	P02011	NUT LOCK M30	2	
10	P02602	WASHER FLAT M16	122	
11	P02603	WASHER FLAT M20	2	
12	P02608	WASHER FLAT M30	8	
13	P11462	DISC BLADE Ø515x6	17	
14	P12620	TOP PLATE	18	
15	P12621	SPACER Ø36xØ16.5x31mm	36	
16	P12622	TRACK ARM	18	
17	P12783	LYNCH PIN CAT 0	18	
18	P12810	NUT CASTLE M24	18	
19	P12815	BOLT M24x185 STRUCTURAL GR 8.8	18	
20	P12886	Ø24xØ16x13mm SPACER BUSH	18	
21	P12930	TRACK ROD RH FRONT 4.6m X-PRESS SL	1	
22	P14009	DISC FRAME 4.6m RH	1	
23	P14014	TRACKROD REAR	1	
24	P14055	SPACER BUSH - 10mm	4	
25	P14216	DISC BLADE Ø457x6	1	
26	P15438	ANGLE GUIDE	2	
27	P17076	ADJUSTER 350-600	2	
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				





DESCRIPTION: DISC FRAME ASSEMBLY LH	MACHINE: X-PRESS 4.6m	© 2005	DRAWN: P.JG DATE: 29/10/2009	PART NO. FROM SERIAL NO. TO SERIAL NO. AS3813	ISSUE A
---	--------------------------	--------	---------------------------------	---	-------------------

AS3813		DISC FRAME LH 4.6M X-PRESS		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	AS3210	DISC UNIT ASSEMBLY RH	9	
2	AS3211	DISC UNIT ASSEMBLY LH	8	
3	AS3242	DISC UNIT - CENTRE	1	
4	P00036	BOLT M30x180 GR. 8.8	2	
5	P00874	BOLT M20x70 GR. 8.8	4	
6	P01704	BOLT M16x50 GR8.8	34	
7	P01901	BOLT M16x80 GR. 8.8	35	
8	P02008	NUT LOCK M16 'TYPE T'	70	
9	P02009	NUT LOCK M20	4	
10	P02010	NUT LOCK M24	1	
11	P02011	NUT LOCK M30	2	
12	P02602	WASHER FLAT M16	121	
13	P02603	WASHER FLAT M20	2	
14	P02608	WASHER FLAT M30	8	
15	P03677	WASHER FLAT M24 Ø70x10	1	
16	P04025	BOLT M24x90 GR. 8.8	1	
17	P11462	DISC BLADE Ø515x6	16	
18	P12620	TOP PLATE	17	
19	P12621	SPACER Ø36xØ16.5x31mm	35	
20	P12622	TRACK ARM	17	
21	P12783	LYNCH PIN CAT 0	17	
22	P12810	NUT CASTLE M24	17	
23	P12815	BOLT M24x185 STRUCTURAL GR 8.8	17	
24	P12886	Ø24xØ16x13mm SPACER BUSH	17	
25	P12928	TRACK ROD FRONT LH 4.6SL X-PRESS	1	
26	P14008	DISC FRAME 4.6m LH	1	
27	P14014	TRACKROD REAR	1	
28	P14055	SPACER BUSH - 10mm	4	
29	P14216	DISC BLADE Ø457x6	1	
30	P15438	ANGLE GUIDE	2	
31	P17076	ADJUSTER 350-600	2	
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				





DESCRIPTION: DISC FRAME ASSEMBLY 5.5m RH	MACHINE: X-PRESS 5.5m	© 2007	DRAWN:- P.J.G DATE:- 29/10/2009	PART NO. FROM SERIAL NO. TO SERIAL NO.	ASSEMBLY AS3814	ISSUE A
---	--------------------------	--------	------------------------------------	--	--------------------	------------

AS3814		X-PRESS 5.5m DISC FRAME RH		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	AS3210	DISC UNIT ASSEMBLY RH	11	
2	AS3211	DISC UNIT ASSEMBLY LH	11	
3	P00036	BOLT M30x180 GR. 8.8	2	
4	P00874	BOLT M20x70 GR. 8.8	4	
5	P01704	BOLT M16x50 GR8.8	44	
6	P01901	BOLT M16x80 GR. 8.8	44	
7	P02008	NUT LOCK M16 'TYPE T'	88	
8	P02009	NUT LOCK M20	4	
9	P02011	NUT LOCK M30	2	
10	P02602	WASHER FLAT M16	150	
11	P02603	WASHER FLAT M20	4	
12	P02608	WASHER FLAT M30	8	
13	P11462	DISC BLADE Ø515x6	21	
14	P12620	TOP PLATE	22	
15	P12621	SPACER Ø36xØ16.5x31mm	44	
16	P12622	TRACK ARM	22	
17	P12783	LYNCH PIN CAT 0	22	
18	P12810	NUT CASTLE M24	22	
19	P12815	BOLT M24x185 STRUCTURAL GR 8.8	22	
20	P12886	Ø24xØ16x13mm SPACER BUSH	22	
21	P12897	TRACK ROD RH FRONT 5.5m X-PRESS SL	1	
22	P14011	DISC FRAME 5.5m RH	1	
23	P14015	TRACKROD REAR	1	
24	P14055	SPACER BUSH - 10mm	4	
25	P14216	DISC BLADE Ø457x6	1	
26	P15438	ANGLE GUIDE	2	
27	P17076	ADJUSTER 350-600	2	
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				





DESCRIPTION:- DISC FRAME ASSEMBLY 5.5m LH	MACHINE:- X-PRESS 5.5m	DRAWN:- PJG DATE:- 29/10/2009	PART NO. FROM SERIAL NO. TO SERIAL NO. AS3815	ISSUE A
---	---------------------------	----------------------------------	---	-------------------

AS3815		X-PRESS 5.5m DISC FRAME LH		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	AS3210	DISC UNIT ASSEMBLY RH	11	
2	AS3211	DISC UNIT ASSEMBLY LH	10	
3	AS3242	DISC UNIT - CENTRE	1	
4	P00036	BOLT M30x180 GR. 8.8	2	
5	P00874	BOLT M20x70 GR. 8.8	4	
6	P01704	BOLT M16x50 GR8.8	42	
7	P01901	BOLT M16x80 GR. 8.8	43	
8	P02008	NUT LOCK M16 'TYPE T'	86	
9	P02009	NUT LOCK M20	4	
10	P02010	NUT LOCK M24	1	
11	P02011	NUT LOCK M30	2	
12	P02602	WASHER FLAT M16	147	
13	P02603	WASHER FLAT M20	4	
14	P02608	WASHER FLAT M30	8	
15	P03677	WASHER FLAT M24 Ø70x10	1	
16	P04025	BOLT M24x90 GR. 8.8	1	
17	P11462	DISC BLADE Ø515x6	20	
18	P12620	TOP PLATE	21	
19	P12621	SPACER Ø36xØ16.5x31mm	43	
20	P12622	TRACK ARM	21	
21	P12783	LYNCH PIN CAT 0	21	
22	P12810	NUT CASTLE M24	21	
23	P12815	BOLT M24x185 STRUCTURAL GR 8.8	21	
24	P12886	Ø24xØ16x13mm SPACER BUSH	21	
25	P12896	TRACK ROD FRONT LH 5.5SL X-PRESS	1	
26	P14010	DISC FRAME 5.5 LH	1	
27	P14015	TRACKROD REAR	1	
28	P14055	SPACER BUSH - 10mm	4	
29	P14216	DISC BLADE Ø457x6	1	
30	P15438	ANGLE GUIDE	2	
31	P17076	ADJUSTER 350-600	2	
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				





DESCRIPTION:- DISC FRAME ASSEMBLY 6.6m RH	MACHINE:- X-PRESS 6.6m	 © 2007	DRAWN:- KSL DATE:- 02/11/2009	PART NO. FROM SERIAL NO. TO SERIAL NO.	ASSEMBLY AS3816	ISSUE A
--	---------------------------	--	----------------------------------	--	--------------------	------------

AS3816		DISC FRAME ASSEMBLY 6.6m RH		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	AS3210	DISC UNIT ASSEMBLY RH	13	
2	AS3211	DISC UNIT ASSEMBLY LH	13	
3	P00036	BOLT M30x180 GR. 8.8	2	
4	P00874	BOLT M20x70 GR. 8.8	4	
5	P01704	BOLT M16x50 GR8.8	52	
6	P01901	BOLT M16x80 GR. 8.8	52	
7	P02008	NUT LOCK M16 'TYPE T'	104	
8	P02009	NUT LOCK M20	4	
9	P02011	NUT LOCK M30	2	
10	P02602	WASHER FLAT M16	178	
11	P02603	WASHER FLAT M20	4	
12	P02608	WASHER FLAT M30	8	
13	P11462	DISC BLADE Ø515x6	25	
14	P12620	TOP PLATE	26	
15	P12621	SPACER Ø36xØ16.5x31mm	52	
16	P12622	TRACK ARM	26	
17	P12783	LYNCH PIN CAT 0	26	
18	P12810	NUT CASTLE M24	26	
19	P12815	BOLT M24x185 STRUCTURAL GR 8.8	26	
20	P12821	TRACK ROD RH FRONT 6.6m X-PRESS SL	1	
21	P12886	Ø24xØ16x13mm SPACER BUSH	26	
22	P14013	DISC FRAME 6.6 RH	1	
23	P14016	TRACKROD - REAR	1	
24	P14055	SPACER BUSH - 10mm	4	
25	P14216	DISC BLADE Ø457x6	1	
26	P15438	ANGLE GUIDE	2	
27	P17076	ADJUSTER 350-600	2	
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				





DESCRIPTION: 6.6m DISC FRAME ASSEMBLY LH	MACHINE: X-PRESS 6.6m	© 2007	DRAWN:- KSL DATE:- 02/11/2009	PART NO. FROM SERIAL NO. TO SERIAL NO.	ASSEMBLY AS3817	ISSUE A
---	--------------------------	--------	----------------------------------	--	--------------------	------------

AS3817		DISC FRAME ASSEMBLY 6.6m LH		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	AS3210	DISC UNIT ASSEMBLY RH	13	
2	AS3211	DISC UNIT ASSEMBLY LH	12	
3	AS3242	DISC UNIT - CENTRE	1	
4	P00036	BOLT M30x180 GR. 8.8	2	
5	P00874	BOLT M20x70 GR. 8.8	4	
6	P01704	BOLT M16x50 GR8.8	50	
7	P01901	BOLT M16x80 GR. 8.8	51	
8	P02008	NUT LOCK M16 'TYPE T'	102	
9	P02009	NUT LOCK M20	4	
10	P02010	NUT LOCK M24	1	
11	P02011	NUT LOCK M30	2	
12	P02602	WASHER FLAT M16	163	
13	P02603	WASHER FLAT M20	4	
14	P02608	WASHER FLAT M30	8	
15	P03677	WASHER FLAT M24 Ø70x10	1	
16	P04025	BOLT M24x90 GR. 8.8	1	
17	P11462	DISC BLADE Ø515x6	24	
18	P12620	TOP PLATE	25	
19	P12621	SPACER Ø36xØ16.5x31mm	51	
20	P12622	TRACK ARM	25	
21	P12783	LYNCH PIN CAT 0	25	
22	P12810	NUT CASTLE M24	25	
23	P12815	BOLT M24x185 STRUCTURAL GR 8.8	25	
24	P12822	TRACK ROD FRONT LH 6.6SL X-PRESS	1	
25	P12886	Ø24xØ16x13mm SPACER BUSH	25	
26	P14012	DISC FRAME 6.6m LH	1	
27	P14016	TRACKROD - REAR	1	
28	P14055	SPACER BUSH - 10mm	4	
29	P14216	DISC BLADE Ø457x6	1	
30	P15438	ANGLE GUIDE	2	
31	P17076	ADJUSTER 350-600	2	
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				





DESCRIPTION: DISC UNIT ASSEMBLY RH	MACHINE: X-PRESS	© 2007	DRAWN:- P.J.G DATE:- 10/09/2007	PART NO. FROM SERIAL NO. TO SERIAL NO.	ASSEMBLY AS3210	ISSUE A
---------------------------------------	---------------------	--------	------------------------------------	--	--------------------	------------

AS3210		DISC UNIT ASSEMBLY RH		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	AS3129	DISC ARM ASSEMBLY RH	1	P14600
2	P02037	WASHER SPRING M12	5	
3	P02601	WASHER FLAT M12	3	
4	P07229	NUT LOCK M12 FINE 1.5	3	
5	P12782	SPRUNG LEAF 20mm	1	
6	P13174	BOLT M12x50 GR10.9 1.5P	3	
7	P15926	BOLT M12x20 GR8.8x1.25	5	
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				





DESCRIPTION:- DISC UNIT ASSEMBLY LH	MACHINE:-	© 2007	DRAWN:- P.J.G DATE:- 10/09/2007	PART NO. FROM SERIAL NO. TO SERIAL NO.	ASSEMBLY AS3211	ISSUE A
--	-----------	--------	------------------------------------	--	--------------------	------------

AS3211		DISC UNIT ASSEMBLY LH		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	AS3130	DISC ARM ASSEMBLY LH	1	P14601
2	P02037	WASHER SPRING M12	5	
3	P02601	WASHER FLAT M12	3	
4	P07229	NUT LOCK M12 FINE 1.5	3	
5	P12782	SPRUNG LEAF 20mm	1	
6	P13174	BOLT M12x50 GR10.9 1.5P	3	
7	P15926	BOLT M12x20 GR8.8x1.25	5	
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				





DESCRIPTION:- DISC UNIT - CENTRE	MACHINE:- X-PRESS	 © 2006	DRAWN:- P.JG DATE:- 28/09/2007	PART NO. FROM SERIAL NO. TO SERIAL NO.	ASSEMBLY AS3242	ISSUE A
--	----------------------	--	-----------------------------------	--	---------------------------	-------------------

AS3242		DISC UNIT ASSEMBLY - CENTRE		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	AS3130	DISC ARM ASSEMBLY LH	1	P14601
2	P01901	BOLT M16x80 GR. 8.8	1	
3	P02037	WASHER SPRING M12	5	
4	P02601	WASHER FLAT M12	3	
5	P07229	NUT LOCK M12 FINE 1.5	3	
6	P11462	DISC BLADE Ø515x6	1	
7	P13174	BOLT M12x50 GR10.9 1.5P	3	
8	P13561	BUSH - CTR LEAF	1	
9	P13673	SPRUNG LEAF CTR 80x20	1	
10	P15926	BOLT M12x20 GR8.8x1.25	5	
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				





DESCRIPTION:- DISC ARM ASSEMBLY RH	MACHINE:- X-PRESS	 © 2007	DRAWN:- P.J.G DATE:- 11/09/2007	PART NO. P14600	FROM SERIAL NO. TO SERIAL NO.	ASSEMBLY AS3129	ISSUE A
--	----------------------	--	------------------------------------	--------------------	-------------------------------	---------------------------	-------------------


AS3129		DISC ARM ASSEMBLY RH		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	P12414	SEAL 64x45x9.5	1	NOT AVAILABLE INDIVIDUALLY
2	P12900	NIPPLE - GREASE M8	1	
3	P12907	NUT CASTLE M27x1.5	1	
4	P12908	SPRING PIN	1	
5	P14591	DISC ARM RH	1	
6	P14593	HUB CASTING	1	
7	P14594	HUB CAP	1	
8	P14595	BEARING 32008 40x68x19	1	NOT AVAILABLE INDIVIDUALLY
9	P14596	BEARING 32206 30x62x21	1	NOT AVAILABLE INDIVIDUALLY
10				
11	P12415	BEARING AND SEAL KIT COMPLETE		INCLUDES ITEMS 1,8,9
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				




DESCRIPTION: DISC ARM ASSEMBLY LH	MACHINE: X-PRESS	© 2007	DRAWN:- P.J.G DATE:- 23/03/2006	PART NO. P14601 FROM SERIAL NO. TO SERIAL NO.	ASSEMBLY AS3130	ISSUE A
--------------------------------------	---------------------	--------	------------------------------------	--	--------------------	------------


AS3130		DISC ARM ASSEMBLY LH			
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS	
1	P12414	SEAL 64x45x9.5	1	NOT AVAILABLE INDIVIDUALLY	
2	P12900	NIPPLE - GREASE M8	1		
3	P12907	NUT CASTLE M27x1.5	1		
4	P12908	SPRING PIN	1		
5	P14592	DISC ARM LH	1		
6	P14593	HUB CASTING	1		
7	P14594	HUB CAP	1		
8	P14595	BEARING 32008 40x68x19	1	NOT AVAILABLE INDIVIDUALLY	
9	P14596	BEARING 32206 30x62x21	1	NOT AVAILABLE INDIVIDUALLY	
10					
11	P12415	BEARING AND SEAL KIT COMPLETE		INCLUDES ITEMS 1,8,9	
12					
13					
14					
15					
16					
17					
18					
19					
20					
21					
22					
23					
24					
25					
26					
27					
28					
29					
30					
31					
32					
33					
34					
35					
36					
37					
38					
39					
40					
41					
42					
43					
44					
45					
46					
47					
48					
49					
50					




AS2157		DISC FRAME ADJUSTER ASSEMBLY		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	P14097	CAT 3 TOPLINK C/W CLEVIS ENDS	1	
2	P00017	BOLT M24x100 GR. 8.8	2	
3	P02604	WASHER FLAT M24 Ø50	4	
4	P02010	NUT LOCK M24	2	
5	P08802	SHIM KIT 7 PIECE	1	
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				





DESCRIPTION:- ROLL FRAME ASSEMBLY - RH 4.6m	MACHINE:- X-PRESS 4.6m	© 2007	DRAWN:- P.JG DATE:- 06/10/2007	PART NO.	FROM SERIAL NO. TO SERIAL NO.	ASSEMBLY AS3252	ISSUE B
--	---------------------------	--------	-----------------------------------	----------	-------------------------------	--------------------	------------

AS3252		ROLL FRAME ASSEMBLY - RH 4.6m		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	P00071	NIPPLE - GREASE	2	
2	P01645	BUSH SPRUNG - Ø32xØ26x30	2	
3	P02010	NUT LOCK M24	1	
4	P02604	WASHER FLAT M24 Ø50	2	
5	P12610	BOLT M24x120 GR 10.9 STR	1	
6	P14862	4.6m RH ROLL FRAME	1	
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				





DESCRIPTION: ROLL FRAME ASSEMBLY - LH 4.6m	MACHINE: X-PRESS 4.6m	© 2007	DRAWN:- P.JG DATE:- 09/10/2007	PART NO. FROM SERIAL NO. TO SERIAL NO. AS3253	ISSUE A
---	--------------------------	--------	-----------------------------------	--	------------

AS3253		ROLL FRAME ASSEMBLY - LH 4.6m		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	P00071	NIPPLE - GREASE	2	
2	P01645	BUSH SPRUNG - Ø32xØ26x30	2	
3	P02010	NUT LOCK M24	1	
4	P02604	WASHER FLAT M24 Ø50	2	
5	P12610	BOLT M24x120 GR 10.9 STR	1	
6	P14861	ROLL FRAME LH 4.6m	1	
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				





DESCRIPTION: ROLL FRAME ASSEMBLY - 5.5m RH	MACHINE: X-PRESS 5.5m	© 2007	DRAWN:- P.J.G DATE:- 06/10/2007	PART NO. FROM SERIAL NO. TO SERIAL NO.	ASSEMBLY AS3254	ISSUE A
--	--------------------------	--------	------------------------------------	--	---------------------------	-------------------


AS3254		ROLL FRAME ASSEMBLY - 5.5m RH		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	P00071	NIPPLE - GREASE	2	
2	P01645	BUSH SPRUNG - Ø32xØ26x30	3	
3	P02010	NUT LOCK M24	2	
4	P02604	WASHER FLAT M24 Ø50	4	
5	P12610	BOLT M24x120 GR 10.9 STR	2	
6	P14864	ROLL FRAME 5.5m RH	1	
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				





DESCRIPTION:- ROLL FRAME ASSEMBLY 5.5m LH	MACHINE:- X-PRESS 5.5m	© 2007	DRAWN:- P.J.G DATE:- 06/10/2007	PART NO. FROM SERIAL NO. TO SERIAL NO.	ASSEMBLY AS3255	ISSUE A
---	---------------------------	--------	------------------------------------	--	---------------------------	-------------------


AS3255		ROLL FRAME ASSEMBLY - 5.5m LH		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	P00071	NIPPLE - GREASE	2	
2	P01645	BUSH SPRUNG - Ø32xØ26x30	3	
3	P02010	NUT LOCK M24	2	
4	P02604	WASHER FLAT M24 Ø50	4	
5	P12610	BOLT M24x120 GR 10.9 STR	2	
6	P14863	ROLL FRAME LH 5.5m	1	
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				




AS3256		ROLL FRAME ASSEMBLY - 6.6m RH		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	P00071	NIPPLE - GREASE	2	
2	P01645	BUSH SPRUNG - Ø32xØ26x30	4	
3	P02010	NUT LOCK M24	2	
4	P02604	WASHER FLAT M24 Ø50	4	
5	P12610	BOLT M24x120 GR 10.9 STR	2	
6	P14866	ROLL FRAME 6.6m RH	1	
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				




AS3257		ROLL FRAME ASSEMBLY - 6.6m LH		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	P00071	NIPPLE - GREASE	2	
2	P01645	BUSH SPRUNG - Ø32xØ26x30	4	
3	P02010	NUT LOCK M24	2	
4	P02604	WASHER FLAT M24 Ø50	4	
5	P12610	BOLT M24x120 GR 10.9 STR	2	
6	P14865	ROLL FRAME 6.6m LH	1	
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				





DESCRIPTION: DD700 ROLL ASSEMBLY RH	 © 2005	DRAWN:- P.JG DATE:- 09/10/2007	PART NO. FROM SERIAL NO. TO SERIAL NO.	ASSEMBLY AS3258	ISSUE A
--	--	-----------------------------------	--	--------------------	------------

AS3258		DD700 ASSEMBLY - RH 4.6m		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	AS0775	AXLE ASSEMBLY - DD700 5 RINGS	2	
2	P09560	SCRAPER STEM LH	1	
3	P02037	WASHER SPRING M12	18	
4	P10870	BOLT M12x30 GR. 8.8	18	
5	P02602	WASHER FLAT M16	10	
6	P02008	NUT LOCK M16	10	
7	P06802	BOLT U M16 GR8.8 190x117	5	
8	P09558	SCRAPER PLATE	8	
9	P10029	SCRAPER 1 1/2	1	
10	P09559	SCRAPER STEM RH	4	
11	P04179	WASHER FLAT M12 Ø38	18	
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				





DESCRIPTION: DD700 ROLL ASSEMBLY LH	MACHINE: X-PRESS 4.6m	 © 2007	DRAWN:- P.JG DATE:- 06/10/2007	PART NO. FROM SERIAL NO. TO SERIAL NO.	ASSEMBLY AS3259	ISSUE A
--	--------------------------	--	-----------------------------------	--	--------------------	------------

AS3259		DD700 ROLL ASSEMBLY - LH 4.6m		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	AS0775	AXLE ASSEMBLY - DD700 5 RINGS	2	
2	P02008	NUT LOCK M16	10	
3	P02037	WASHER SPRING M12	16	
4	P02602	WASHER FLAT M16	10	
5	P04179	WASHER FLAT M12 Ø38	18	
6	P06802	BOLT U M16 GR8.8 190x117	5	
7	P09558	SCRAPER PLATE	8	
8	P09559	SCRAPER STEM RH	1	
9	P09560	SCRAPER STEM LH	4	
10	P10029	SCRAPER 1 1/2	1	
11	P10870	BOLT M12x30 GR. 8.8	18	
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				





DESCRIPTION: DD700 ROLL ASSEMBLY - 5.5m RH	MACHINE: X-PRESS 5.5m	 © 2007	DRAWN:- P.JG DATE:- 06/10/2007	PART NO. FROM SERIAL NO. TO SERIAL NO. AS3260	ISSUE A
---	--------------------------	--	-----------------------------------	--	------------

AS3260		DD700 ROLL ASSEMBLY - 5.5m RH		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	AS0776	AXLE ASSEMBLY - DD700 6 RINGS	2	
2	P02008	NUT LOCK M16	14	
3	P02037	WASHER SPRING M12	22	
4	P02602	WASHER FLAT M16	14	
5	P04179	WASHER FLAT M12 Ø38	22	
6	P06802	BOLT U M16 GR8.8 190x117	7	
7	P09558	SCRAPER PLATE	10	
8	P09559	SCRAPER STEM RH	5	
9	P09560	SCRAPER STEM LH	2	
10	P10029	SCRAPER 1 1/2	1	
11	P10870	BOLT M12x30 GR. 8.8	22	
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				





DESCRIPTION: DD700 ROLL ASSEMBLY - 5.5m LH	MACHINE: X-PRESS 5.5m	© 2007	DRAWN:- P.J.G DATE:- 06/10/2007	PART NO. FROM SERIAL NO. TO SERIAL NO. AS3261	ISSUE A
---	--------------------------	--------	------------------------------------	--	------------

AS3261		DD700 ROLL ASSEMBLY - 5.5m LH		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	AS0776	AXLE ASSEMBLY - DD700 6 RINGS	2	
2	P02008	NUT LOCK M16	14	
3	P02037	WASHER SPRING M12	22	
4	P02602	WASHER FLAT M16	14	
5	P04179	WASHER FLAT M12 Ø38	22	
6	P06802	BOLT U M16 GR8.8 190x117	7	
7	P09558	SCRAPER PLATE	10	
8	P09559	SCRAPER STEM RH	2	
9	P09560	SCRAPER STEM LH	5	
10	P10029	SCRAPER 1 1/2	1	
11	P10870	BOLT M12x30 GR. 8.8	22	
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				





DESCRIPTION:- DD700 ROLL ASSEMBLY - 6.6m RH	MACHINE:- X-PRESS 6.6m	 © 2007	DRAWN:- P.J.G DATE:- 08/10/2007	PART NO. FROM SERIAL NO. TO SERIAL NO.	ASSEMBLY AS3262	ISSUE A
--	---------------------------	--	------------------------------------	--	--------------------	------------

AS3262		DD700 ROLL ASSEMBLY - 6.6m RH		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	AS0643	AXLE ASSEMBLY - DD700 7 RINGS	2	
2	P02008	NUT LOCK M16	18	
3	P02037	WASHER SPRING M12	23	
4	P02602	WASHER FLAT M16	18	
5	P04179	WASHER FLAT M12 Ø38	26	
6	P06802	BOLT U M16 GR8.8 190x117	9	
7	P09558	SCRAPER PLATE	12	
8	P09559	SCRAPER STEM RH	7	
9	P09560	SCRAPER STEM LH	2	
10	P10029	SCRAPER 1 1/2	1	
11	P10870	BOLT M12x30 GR. 8.8	26	
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				





DESCRIPTION: 6.6m ROLL CARRIER ASSEMBLY LH	MACHINE: X-PRESS 6.6m	 © 2007	DRAWN:- P.JG DATE:- 05/07/2006	PART NO. FROM SERIAL NO. TO SERIAL NO. AS3263	ISSUE A
---	--------------------------	--	-----------------------------------	--	------------

AS3263		DD700 ROLL ASSEMBLY - 6.6m LH		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	AS0643	AXLE ASSEMBLY - DD700 7 RINGS	2	
2	P02008	NUT LOCK M16	18	
3	P02037	WASHER SPRING M12	26	
4	P02602	WASHER FLAT M16	18	
5	P04179	WASHER FLAT M12 Ø38	26	
6	P06802	BOLT U M16 GR8.8 190x117	9	
7	P09558	SCRAPER PLATE	12	
8	P09559	SCRAPER STEM RH	2	
9	P09560	SCRAPER STEM LH	7	
10	P10029	SCRAPER 1 1/2	1	
11	P10870	BOLT M12x30 GR. 8.8	26	
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				





DESCRIPTION:- AXLE ASSEMBLY - DD700 5 RINGS	 © 2004	DRAWN:- ARH DATE:- 27/04/2004	PART NO. FROM SERIAL NO. TO SERIAL NO.	ASSEMBLY AS0775	ISSUE B
--	--	----------------------------------	--	--------------------	------------


AS0775		AXLE ASSEMBLY DD700 5 RINGS		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	AS0658	PILLAR ASSEMBLY DD600	2	
2	P07727	AXLE Ø60x1135	1	
3	P08190	DD 600 - NUT SPOOL	2	
4	P08994	DD RING Ø700	10	
5	P08191	DD 600 - INTERNAL SPACER	5	
6	P08189	DD 600 - BEARING SPOOL	4	
7	P08188	DD 600 - SPOOL	2	
8	P02489	PIN SPLIT Ø10x100	1	
9	P01698	NUT CASTLE M60	1	
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				




DESCRIPTION: AXLE ASSEMBLY - DD700 6 RINGS	© 2004	DRAWN:- ARH DATE:- 27/04/2004	PART NO. FROM SERIAL NO. TO SERIAL NO.	ASSEMBLY AS0776	ISSUE B
---	--------	----------------------------------	--	--------------------	------------


AS0776		AXLE ASSEMBLY DD700 6 RINGS		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	AS0658	PILLAR ASSEMBLY DD600	2	
2	P07728	AXLE Ø60x1369	1	
3	P08190	DD 600 - NUT SPOOL	2	
4	P08994	DD RING Ø700	12	
5	P08191	DD 600 - INTERNAL SPACER	6	
6	P08189	DD 600 - BEARING SPOOL	4	
7	P08188	DD 600 - SPOOL	3	
8	P02489	PIN SPLIT Ø10x100	1	
9	P01698	NUT CASTLE M60	1	
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				




AS0643		AXLE ASSEMBLY DD700 7 RINGS		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	AS0658	PILLAR ASSEMBLY DD600	2	
2	P07729	AXLE Ø60x1623	1	
3	P08190	DD 600 - NUT SPOOL	2	
4	P08994	DD RING Ø700	14	
5	P08191	DD 600 - INTERNAL SPACER	7	
6	P08189	DD 600 - BEARING SPOOL	4	
7	P08188	DD 600 - SPOOL	4	
8	P02489	PIN SPLIT Ø10x100	1	
9	P01698	NUT CASTLE M60	1	
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				





DESCRIPTION: PILLAR ASSEMBLY DD600	SIMBA © 2004	DRAWN:- ARH DATE:- 23/04/2004	PART NO. FROM SERIAL NO. TO SERIAL NO.	ASSEMBLY AS0658	ISSUE C
---------------------------------------	--------------	----------------------------------	--	--------------------	------------

AS0658		PILLAR ASSEMBLY DD600 + 700		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	P07696	PRESS ROLL PILLAR	1	
2	P05431	BEARING - PRESSED STEEL	1	
3	P08276	GREASE PIPE	1	
4	P08450	BEARING GUARD	1	
5	P08298	SPACER 10mm	2	
6	P00057	BOLT M16x60 GR. 8.8	2	
7	P02602	WASHER FLAT M16	4	
8	P02008	NUT LOCK M16	4	
9	P01704	BOLT M16x50 GR. 8.8	2	
10	P02603	WASHER FLAT M20	4	
11	P02009	NUT LOCK M20	4	
12	P01619	BOLT U M20 GR8.8 145x172	2	
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				





DESCRIPTION:- BRAKED AXLE ASSEMBLY - AIR	MACHINE:- X-PRESS	 © 2007	DRAWN:- P.J.G DATE:- 22/03/2007	PART NO. FROM SERIAL NO. TO SERIAL NO.	ASSEMBLY AS2972	ISSUE D
--	----------------------	--	------------------------------------	--	---------------------------	-------------------

AS2972		BRAKED AXLE ASSEMBLY - AIR		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	P02007	NUT LOCK M12	8	
2	P02035	WASHER SPRING M10	2	
3	P02601	WASHER FLAT M12	16	
4	P03087	BOLT M12x50 GR. 8.8	8	
5	P03112	BOLT M12x150 GR. 8.8	8	
6	P12690	BOLT M10x30 GR. 8.8	2	
7	P13248	BRAKE CHAMBER OIL/AIR	2	
8	P13733	BLANKING CAP 3/8"	2	
9	P14540	DUST CAP	1	
10	P14544	AIR HOSE FITTING M22	1	
11	P14547	AIR HOSE FITTING M22	1	
12	P15189	BRAKED AXLE 6 STUD	1	
13	P15214	RELAY-EMERGENCY VALVE	1	
14	P15495	RETAINING PLATE	2	
15	P15503	BLANKING PLUG - M16	4	
16	P15506	STR FITTING - M16	1	
17	P15508	CHAMBER MOUNT LH	1	
18	P15513	CHAMBER MOUNT RH	1	
19	P15533	M/F REDUCER - M22-M16	2	
20	P15540	TEST POINT M16	1	
21	P15542	FLEXI AIR HOSE - 1000mm	1	
22	P15543	FLEXI AIR HOSE - 500mm	1	
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				





DESCRIPTION: AIR TANK AND FITTINGS	MACHINE: X-PRESS	 © 2007	DRAWN:- P.J.G DATE:- 23/03/2007	PART NO. FROM SERIAL NO. TO SERIAL NO. AS2973	ISSUE B
---------------------------------------	---------------------	--	------------------------------------	--	------------


AS2973		AIR TANK AND FITTINGS		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	P00007	BOLT M16x40 GR. 8.8	2	
2	P01709	NUT STAYTIGHT M16	2	
3	P02003	NUT PLAIN M10	2	
4	P02008	NUT LOCK M16	2	
5	P02035	WASHER SPRING M10	4	
6	P02602	WASHER FLAT M16	6	
7	P05401	WASHER SPRING M6	8	
8	P07981	NUT LOCK M6	4	
9	P10293	BOLT M6x20 GR. 8.8	4	
10	P12690	BOLT M10x30 GR. 8.8	4	
11	P14497	AIR TANK 20L	1	
12	P14542	AIR TANK DRAIN	1	
13	P14547	AIR HOSE FITTING M22	1	
14	P15209	PALM COUPLER STOWAGE	2	
15	P15210	INLINE AIR FILTER	2	
16	P15222	YELLOW AIR LINE	1	
17	P15223	RED AIR LINE	1	
18	P15224	SHUNT VALVE	1	
19	P15225	PALM COUPLING	2	
20	P15496	AIR TANK BRACKET	1	
21	P15497	MOUNTING STRAP	1	
22	P15498	BULKHEAD	1	
23	P15532	BLANKING PLUG	1	
24	P15534	AIR FITTING 90° M16	1	
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				




MACHINE: X-PRESS	 © 2007	DRAWN:- P.J.G DATE:- 22/03/2007	PART NO. FROM SERIAL NO. TO SERIAL NO.	ASSEMBLY AS2971	ISSUE C
DESCRIPTION: BRAKED AXLE ASSEMBLY - OIL					


AS2971		BRAKED AXLE ASSEMBLY - OIL		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	P02007	NUT LOCK M12	8	
2	P02601	WASHER FLAT M12	16	
3	P03087	BOLT M12x50 GR. 8.8	8	
4	P03112	BOLT M12x150 GR. 8.8	8	
5	P09318	T ADAPTOR 3/8" BSP	1	
6	P13248	BRAKE CHAMBER OIL/AIR	2	
7	P15189	BRAKED AXLE 6 STUD	1	
8	P15495	RETAINING PLATE	2	
9	P15503	BLANKING PLUG - M16	4	
10	P15508	CHAMBER MOUNT LH	1	
11	P15513	CHAMBER MOUNT RH	1	
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				




AS2982		HOSE LAYOUT - HYDRAULIC BRAKES		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	P02263	DOWTY SEAL 1/2" BSP	1	
2	P03686	ADAPTOR MALE - MALE 1/2"-3/8" BSP	1	
3	P09318	T ADAPTOR 3/8" BSP	1	
4	P10128	QRC - BRAKE	1	
5	P13248	BRAKE CHAMBER OIL/AIR	2	
6	P15544	HA 1/4" X 7900mm	1	
7	P15545	HA 1/4" X 1235mm	2	90° SWEEP BOTH ENDS
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				





DESCRIPTION:- LIFT CIRCUIT - HYD. COMPONENT LAYOUT	MACHINE:- X-PRESS	DRAWN:- P.J.G DATE:- 03/11/2005	PART NO. FROM SERIAL NO. TO SERIAL NO.	ASSEMBLY AS2158	ISSUE B
---	----------------------	------------------------------------	--	--------------------	------------


AS2158		LIFT CIRCUIT - HYD. COMPONENT LAYOUT		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	P12894	CYLINDER Ø120x310	1	
2	P12888	CYLINDER Ø120x310	1	
3	P02263	DOWTY SEAL ½" BSP	8	
4	P02735	BULKHEAD ½" BSP	2	
5	P06216	ADAPTOR T SFOR ½" BSP	2	
6	P00203	ADAPTOR MALE-MALE ½" BSP	4	
7	P03687	DOWTY SEAL 3/8" BSP	4	
8	P03686	ADAPTOR MALE - MALE ½"-3/8" BSP	4	
9	P00206	ADAPTOR MALE-FEM ½" BSP	2	
10	P00774	SHUT OFF TAP ½" BSP	2	
11	P00205	QUICK RELEASE MALE - ½" BSP	2	
12	P00071	NIPPLE - GREASE	4	
13	AS2359	REAR DRAWBAR HYDRAULICS	1	
14	P14172	BLANKING CAP 1/2"	2	
15	P06217	ADAPTOR T SFOE ½" BSP	2	
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				




DESCRIPTION: LIFT CIRCUIT - HYD. HOSE LAYOUT	MACHINE: X-PRESS	© 2005	DRAWN:- P.J.G DATE:- 03/11/2005	PART NO. FROM SERIAL NO. TO SERIAL NO.	ASSEMBLY AS2159	ISSUE B
---	---------------------	--------	------------------------------------	--	--------------------	------------


AS2159		LIFT CIRCUIT - HYD. HOSE LAYOUT		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	P14076	HA 1/2 x 4850 90°	2	
2	P00185	HA 1/2 x 3350	1	
3	P00184	HA 1/2 x 3050	1	
4	P14079	HA 1/2 x 1250 90°/90°	1	
5	P14080	HA 1/2 x 850 90°/90°	1	
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				





AS2748		WING CIRCUIT HYDRAULICS 4.6M X-PRESS		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	P00203	ADAPTOR MALE-MALE 1/2" BSP	11	
2	P02263	DOWTY SEAL 1/2" BSP	13	
3	P00205	QUICK RELEASE MALE - 1/2" BSP	2	
4	P02733	ELBOW 1/2" BSP - F-F	1	
5	P02735	BULKHEAD 1/2" BSP	2	
6	P03686	ADAPTOR MALE - MALE 1/2"-3/8" BSP	6	
7	P03687	DOWTY SEAL 3/8" BSP	10	
8	P06219	BLANKING PLUG 1/2" BSP	5	
9	P06268	BLANKING PLUG - 1/4" BSP	1	
10	P07977	BLANKING PLUG 3/8" BSP	3	
11	P09117	PRESSURE GAUGE 250BAR	1	
12	P11785	ACCUMULATOR 0.7L 10 BAR	1	
13	P12056	DOC + PR RED. MANIFOLD	1	
14	P14090	CONNECTOR BLOCK 3/8" BSP	1	
15	P14172	BLANKING CAP 1/2"	2	
16	AS2358	REAR DRAWBAR HYDRAULICS	1	
17	P08838	ACCUMULATOR 1.4L DIAPHRAGM 10b	1	
18	P12786	CYLINDER - Ø90x400 - 45	2	
19	P06217	ADAPTOR T SFOE 1/2" BSP	4	
20	P08516	GAUGE ADAPTOR 1/4" BSP	1	
21	P09116	GAUGE ADAPTER 1/4" x 1/4" BSP	1	
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				




DESCRIPTION: WING CIRCUIT - HYD. HOSES	MACHINE:- X-PRESS 4.6m	 © 2005	DRAWN:- P.J.G DATE:- 01/02/2008	PART NO. FROM SERIAL NO. TO SERIAL NO.	ASSEMBLY AS3385	ISSUE A
---	---------------------------	--	------------------------------------	--	--------------------	------------


AS3385		HYD. HOSE LAYOUT - X-PRESS 4.6m		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	P14076	HA 1/2" x 4850 90°	2	
2	P14081	HA 1/2" x 2050 90°	1	
3	P14082	HA 1/2" x 1950 90°	1	
4	P14083	HA 1/2" x 650 90°/90°	1	
5	P14084	HA 1/2" x 1050 90°/90°	1	
6	P14621	HA 1/2" x 650 90°/90° @ 90°	1	
7	P14622	HA 1/2" x 1050 90°/90° @ 90°	1	
8	P10199	HA 1/2" x 650	2	
9	P14086	HA 1/2" x 300	2	
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				




AS2160		WING CIRCUIT - HYD. COMPONENTS		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	P00203	ADAPTOR MALE-MALE 1/2" BSP	15	
2	P02263	DOWTY SEAL 1/2" BSP	17	
3	P00205	QUICK RELEASE MALE - 1/2" BSP	2	
4	P02733	ELBOW 1/2" BSP - F-F	1	
5	P02735	BULKHEAD 1/2" BSP	2	
6	P03686	ADAPTOR MALE - MALE 1/2"-3/8" BSP	10	
7	P03687	DOWTY SEAL 3/8" BSP	10	
8	P06219	BLANKING PLUG 1/2" BSP	1	
9	P06268	BLANKING PLUG - 1/4" BSP	1	
10	P07977	BLANKING PLUG 3/8" BSP	3	
11	P09117	PRESSURE GAUGE 250BAR	1	
12	P11785	ACCUMULATOR 0.7L 10 BAR	1	
13	P12056	DOC + PR RED. MANIFOLD	1	
14	P14090	CONNECTOR BLOCK 3/8" BSP	1	
15	P14172	BLANKING CAP 1/2"	2	
16	AS2358	REAR DRAWBAR HYDRAULICS	1	
17	P08838	ACCUMULATOR 1.4L DIAPHRAGM 10b	1	
18	P12786	CYLINDER - Ø90x400 - 45	4	2 ONLY ON 4.6m
19	P06217	ADAPTOR T SFOE 1/2" BSP	4	
20	P08516	GAUGE ADAPTOR 1/4" BSP	1	
21	P09116	GAUGE ADAPTOR 1/4" x 1/4" BSP	1	
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				




DESCRIPTION: WING CIRCUIT - HYD. HOSES	MACHINE: X-PRESS	 © 2005	DRAWN:- P.J.G DATE:- 08/11/2005	PART NO. FROM SERIAL NO. TO SERIAL NO.	ASSEMBLY AS2161	ISSUE D
---	---------------------	--	------------------------------------	--	--------------------	------------

AS2161		WING CIRCUIT - HYD. HOSES 5.5m & 6.6m		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	P14076	HA 1/2" x 4850 90°	2	
2	P14081	HA 1/2" x 2050 90°	1	
3	P14082	HA 1/2" x 1950 90°	1	
4	P14083	HA 1/2" x 650 90°/90°	2	
5	P14084	HA 1/2" x 1050 90°/90°	2	
6	P14621	HA 1/2" x 650 90/90 @ 90°	1	
7	P14622	HA 1/2" x 1050 90/90 @ 90°	1	
8	P10199	HA 1/2" x 650	2	
9	P14086	HA 1/2" x 300	2	
10	P15253	HA 1/2" x 650 90°/90° @ 270°	1	
11	P15254	A 1/2" x 1050 90°/90° @ 270°	1	
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				



DESCRIPTION:- REAR DRAWBAR HYDRAULICS	MACHINE:- X-PRESS	 © 2005	DRAWN:- PJG DATE:- 29/11/2005	PART NO. FROM SERIAL NO. TO SERIAL NO.	ASSEMBLY AS2358	ISSUE B
--	----------------------	--	----------------------------------	--	--------------------	------------

AS2358		REAR DRAWBAR HYDRAULICS		
ITEM	PART NO	DESCRIPTION	QTY	COMMENTS
1	P00774	SHUT OFF TAP ½" BSP	2	
2	P02263	DOWTY SEAL ½" BSP	6	
3	P00203	ADAPTOR MALE-MALE ½" BSP	2	
4	P02730	QUICK RELEASE FEM. ½" BSP	2	
5	P02735	BULKHEAD ½" BSP	2	
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				



SIMBA
Great Plains

Woodbridge Road, Sleaford
Lincolnshire, NG34 7EW

T 01529 304654

F 01529 413468

E simba.international@simba.co.uk

W www.simba.co.uk